POWEROLOGY



Powerology

VORO VOX

Semi-In-Ear Clip USB-C Wired Earphones

SKU: PWXYS11BK-PWXYS11WH

Table of Contents

Product Overview	**2**
Package Contents	**2**
Safety Instructions	**2**
Using VORO VOX	**4**
Specifications	**5**
Features	**5**
Care and Maintenance	**5**
Frequently Asked Questions	**6**
Troubleshooting	**8**
Disposal	**10**
Warranty	**10**
Contact Us	**10**

Product Overview

VORO VOX is a pair of semi-in-ear clip USB-C wired earphones designed for comfortable everyday listening. It combines an ergonomic clip-on fit, immersive audio, a built-in microphone, an in-line control and a durable braided cable for convenient music and call management.



Package Contents

1. VORO VOX × 1

Safety Instructions

Warning:

1. Do not listen at high volume for long periods — prolonged exposure to loud sound can damage your hearing.
2. Do not use the earphones while driving, cycling, or where reduced awareness of surrounding sounds could be dangerous.

3. Keep small parts away from young children — choking hazard.
4. Keep the cable away from young children — entanglement and strangulation hazard.
5. Do not use the product if the cable, connector, or housing is damaged.
6. Keep the product dry; do not use it with wet hands or immerse it in liquid.
7. Do not modify, disassemble or attempt to repair the product; discontinue use if it malfunctions and seek appropriate support.

Attention:

1. Stop using the product if you experience skin irritation or discomfort.
2. Keep the product away from heat sources.
3. Disconnect the product by holding the USB-C connector, not by pulling the cable.
4. Avoid sharply bending, crushing, or placing heavy objects on the cable.
5. Clean the product with a soft, dry cloth; do not use harsh chemicals.
6. Keep this manual for future reference.



Using VORO VOX

1. Connecting the Earphones

Reduce the connected device's volume before inserting the earphones.

Identify the left and right earpieces and position each clip around the corresponding ear.

Adjust the earpieces until they rest securely and comfortably without applying excessive pressure.

Insert the USB-C connector fully into a compatible smartphone, tablet, laptop or other audio device.

Start audio playback and gradually adjust the volume to a comfortable level.

2. Music Playback

Connect VORO VOX to the device's USB-C port.

Open the preferred audio application and begin playback.

Use the in-line control to play or pause audio.

Use the + and - buttons to adjust the volume.

Disconnect the earphones by holding the connector housing rather than pulling the cable.

3. Managing Calls

Keep VORO VOX connected to the device when a call arrives.

Use the in-line control to answer the incoming call.

Speak normally toward the built-in microphone.

Use the in-line control again to end the call.

If the other person cannot hear you clearly, ensure the microphone is unobstructed and positioned near your mouth.

Specifications

Frequency Response	20Hz–20kHz
Speaker Size	Ø10.4mm
Speaker Impedance	32Ω
Speaker Sensitivity	105 ± 3dB
Microphone Sensitivity	-42 ±3dB
SNR	≥90dB
Cable Length	1.2m
Connector Type	USB-C
Product Material	ABS + TPE
Product Weight	18g
Model Number	PWXYS11

Features

1. 10.4 mm dynamic driver for immersive audio
2. Ergonomic clip-on semi-in-ear design
3. Multi-function in-line control for music and calls
4. Built-in microphone for hands-free calling
5. Durable 1.2 m braided cable
6. USB-C connector

Care and Maintenance

1. Routine Care

Disconnect VORO VOX before cleaning.

Wipe the earpieces, cable and in-line control with a soft, dry cloth.

Remove debris from the speaker openings gently without pushing material into them.

Keep the USB-C connector clean and dry.

Do not use abrasive cleaners, solvents or excessive moisture.

Avoid sharply bending, twisting or knotting the cable.

When not in use, coil the cable loosely and store the earphones in a clean, dry place.

Always disconnect the earphones by gripping the USB-C connector housing.

Frequently Asked Questions

1. Which devices are compatible with VORO VOX?

VORO VOX is intended for compatible devices that support audio through a USB-C connection.

2. Does VORO VOX include a microphone?

Yes. The built-in microphone supports hands-free calls when used with a compatible connected device.

3. Can I control music and calls from the cable?

Yes. The multi-function in-line control manages volume, playback and calls on compatible devices.

4. How should I wear VORO VOX?

Place the left and right earpieces on the corresponding ears, position the clips securely around the ears and adjust them until the fit is comfortable.

5. How should I clean the earphones?

Disconnect them and use a soft, dry cloth. Gently clear debris from the speaker openings and keep moisture away from the USB-C connector.

6. Why do the controls behave differently with some devices?

Control support can vary according to the connected device and its software. Confirm that the device supports USB-C audio and in-line controls.

Troubleshooting

Problem	Likely Cause	Solution
VORO VOX produces no sound	The USB-C connector is loose, the volume is muted or the device does not support USB-C audio.	Reconnect the plug firmly, increase the device volume and confirm that the device supports audio through USB-C.
Sound plays through the device speaker	The earphones were not detected or the audio output was not switched.	Disconnect and reconnect VORO VOX, then select the USB-C audio output in the device settings if available.
Sound is heard from only one earpiece	The connector is not fully inserted, the cable is stressed or the audio balance is adjusted to one side.	Reconnect the plug, straighten the cable gently and check the device's left-right audio balance setting.
Audio is weak or distorted	The volume is too high, the speaker openings are obstructed or the connection is incomplete.	Lower the volume, clean the speaker openings gently and reconnect the USB-C plug.
Audio cuts in and out	The connector is dirty or loose, or the cable is sharply bent.	Clean and reconnect the plug, and position the cable without sharp bends or tension.

Problem	Likely Cause	Solution
The in-line control does not respond	The connected device or application may not support all in-line control functions.	Reconnect the earphones, try the controls in another audio application and confirm device compatibility.
The microphone does not work	Microphone access is disabled, the microphone is obstructed or the application is using another input.	Allow microphone access, keep the microphone clear and select the USB-C microphone in the application settings if available.
Callers cannot hear clearly	The microphone is covered, too far from the mouth or affected by background noise.	Reposition the in-line microphone closer to the mouth, keep it unobstructed and move to a quieter location.
The earphones are not recognized	The USB-C port contains debris, the connection is incomplete or the device does not support USB-C audio.	Inspect and clean the port carefully, reconnect the plug fully and verify USB-C audio support.
The earpieces feel uncomfortable or insecure	The left and right earpieces are reversed or the clips are positioned incorrectly.	Confirm the correct side for each ear and readjust the clips until they rest securely without excessive pressure.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our Powerology website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our Powerology website or store. If Powerology products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website www.powerology.me/warranty and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check: www.powerology.me/warranty

Contact Us

Email: **hey@powerology.me**

Website: **www.powerology.me**

Instagram: **powerology_official**

Facebook: **powerology.ME**