

70 mm

70 mm

70 mm

70 mm

70 mm

70 mm

420 mm

122.5 mm

POWEROLOGY

POWEROLOGY PHANTOM

Wireless Speaker Instructions



User-Manual

MODEL: POWPHANSPK

CE

RoHS

100%

Made in China

Technical Specifications:

Wireless standard: 5.0
Transmission distance: 10 meters
Output power: 10W*2+35W
Play time: 4~5H
Frequency effect: 100Hz~10KHz
Speaker : 57mm*2, 4Ω 10W; 90mm, 4Ω 35W
Input Power: 5V --- 2A
Maximum current consumption: 1A
Battery type: 18650 Li-ion
Battery capacity: 6000mAh
Rated capacity: 3000mAh
Audio signal input interface:
Standard Ø3.5mm headphone jack (stereo)

Features:

1. Wireless connection

2. Memory function

3. Support U disk/ TF card/AUX play mode

4. Built-in lithium battery

5. Support MP3/WAV/WMA/FLAC/APE music format decoding

6. Use high-fidelity speakers, make the sound more natural and delicate

7. 1+1 serial function

8. Water resistance IPX5

9. Mobile power function: 5V, 1A

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

Button instruction:

1. Volume - : short press to reduce the volume.

2. EQ button:
Short press to change the music playing environment mode (indoor, outdoor, Karaoke,...)

3. Series button:
Short press: switch mode function; long press: series function.

4. Play/Pause button:
short press: play/pause;
double-click: call back function under the wireless mode;
short press to answer/ hang up the phone, long press 2 seconds to reject the call under the call mode;
long press to exit wireless connect.

5. Volume +: short press the volume increase.

6. Previous song

7. Wireless indicator

8. Power button long press turn on/off for about 3 seconds/times.

9. Battery level indicator

10. Next song

11. AUX interface

12. USB interface
when inserted into the U disk, the default U disk playback.
Charging mobile devices by default when connecting to mobile devices.

13. TF card interface
when inserted TF card default TF card playback.

14. Type-C interface
when inserted into the Type-C data cable defaults to charging the device.

15. Reset button

Directions for use:

1. Device to connect
1.1 Turn on the device to default wireless mode.
1.2 Turn on wireless device, search model PHANTOM and connect, play music after connection successfully.

2. Suitable for all kinds of mobile phones equipped with wireless technology, wireless adapter, wireless players.

3. Voice prompt
3.1, there is a voice prompt when turn on/off.
3.2. Low-power voice prompt 3 times, shutdown after 155; no charge state.

4. Mode switching
4.1, enter into wireless by default when starting-up, switching sequence is as follows:
wireless mode -TF card mode -USB mode -AUX mode.
4.2. mode: post-insertion priority.

5. LED light
Battery level indicator

charging:

Battery Level	LED 1	LED 1	LED 1	LED 1
1%~25%	flicker	lights off	lights off	lights off
26%~50%	light	flicker	lights off	lights off
51%~75%	light	light	flicker	lights off
76%~100%	light	light	light	flicker
Full Power	light	light	light	light

playing:

Battery Level	LED 1	LED 1	LED 1	LED 1
1%~25%	light	lights off	lights off	lights off
26%~50%	light	light	lights off	lights off
51%~75%	light	light	light	lights off
76%~100%	light	light	light	light

5.2 Indicator:
Wireless search status: the white light flashes quickly, about 0.5 seconds/time;
Wireless pairing status: white light is always on, Play status: The white light flashes slowly for about 1.5 seconds/time;
6. Volume:
the default volume of speaker is 70% when starting-up.
7. Charging to use
The machine built overcharge protection circuit, can be connected to a computer or charger for a long time, about four hours to fully charge. Every battery playback time will be different due to the use of different size of the volume.
8. No working status, automatic shutdown after 15 minutes.

Troubleshooting:

1. Auto power off: the battery protection is automatically activated when the battery is low, please use it after charging for 5 hours.

2. Can not play music: the music file storage path cannot be recognized, save file and store in the root directory of the removable device.

3. Connect the computer no sound: computer interface connection error, please select the correct audio output port.

4. No function or function keys wrong: try again after shutdown.

5. If the machine appears abnormal, short press the reset button to reset.

hey@powerology.me | www.powerology.me

f powerology

@ powerology.me

تعليمات الإستخدام

5.2 المؤشر:
حالة البحث اللاسلكي: يومض الضوء الأبيض بسرعة ، حوالي 0.5 ثانية / وقت ؛
حالة الاقتران اللاسلكي: الضوء الأبيض مضاء دائما. حالة التشغيل: يومض الضوء الأبيض ببطء لمدة 1.5 ثانية / مرة ؛
6. الصوت:
الصوت الافتراضي للسماعة هو 70٪ عند بدء التشغيل.
7. شحن للاستخدام
يمكن توصيل دائرة حماية الشحن الزائد بجهاز كمبيوتر أو شاحن لفترة طويلة ، حوالي أربع ساعات لشحنها بالكامل. سيكون كل وقت تشغيل للبطارية مختلفًا بسبب استخدام أحجام مختلفة لمستوى الصوت.
8. لا يوجد حالة عمل ، إغلاق تلقائي بعد 15 دقيقة.

استكشاف الأخطاء وإصلاحها:

1. إيقاف التشغيل التلقائي: يتم تنشيط حماية البطارية تلقائيًا عندما تكون البطارية منخفضة ، يرجى استخدامها بعد الشحن لمدة 5 ساعات.

2. لا يمكن تشغيل الموسيقى: لا يمكن التعرف على مسار تخزين ملفات الموسيقى ، حفظ الملف وتخزينه في الدليل للجهاز القابل للإزالة.

3. تم توصيل الكمبيوتر بلا صوت: خطأ في اتصال واجهة الكمبيوتر ، يرجى تحديد منفذ إخراج الصوت الصحيح.

4. لا توجد وظيفة أو مفاتيح وظيفية خاطئة: حاول مرة أخرى بعد إيقاف التشغيل.

5. إذا ظهر الجهاز بشكل غير طبيعي ، فاضغط لفترة قصيرة على زر إعادة الضبط لإعادة الضبط.

hey@powerology.me | www.powerology.me
f powerology @ powerology.me

تعليمات الزر:

1. الصوت - : اضغط لفترة وجيزة لخفض مستوى الصوت.
2. زر EQ:
ضغطه قصيرة لتغيير بيئة تشغيل الموسيقى (داخلي ، خارجي ، كاريوكي ...) ،
3. زر السلسلة:
الضغط القصير: وظيفة وضع التبديل ؛ الضغط لفترة طويلة: وظيفة السلسلة.
4. زر التشغيل / الإيقاف المؤقت:
ضغطه قصيرة: تشغيل / إيقاف مؤقت ؛
انقر نقرًا مزدوجًا: وظيفة معاودة الاتصال تحت الوضع اللاسلكي ؛
اضغط لفترة وجيزة للرد / تعليق الهاتف ، اضغط لفترة طويلة ثابتهان لرفض المكالمات تحت وضع الاتصال ؛
اضغط لفترة طويلة للخروج من الاتصال اللاسلكي.
5. صوت + : باختصار اضغط على زيادة صوت.
6. الأغنية السابقة
7. مؤشر لاسلكي
8. اضغط على زر الطاقة لفترة طويلة تشغيل / إيقاف لمدة 3 ثوانٍ / مرات.

9. مؤشر مستوى البطارية
10. الأغنية التالية
11. واجهة AUX
12. واجهة USB
عند إدخاله في قرص U ، تشغيل قرص U الافتراضي.
شحن الأجهزة المحمولة بشكل افتراضي عند الاتصال بالأجهزة المحمولة.
13. واجهة بطاقة TF
عند إدخال بطاقة TF الافتراضية تشغيل بطاقة TF.
14. واجهة تايب-سي
عند إدخاله في كابل البيانات تايب-سي ، يتم شحن الجهاز بشكل افتراضي.
15. زر إعادة الضبط

المواصفات الفنية:

المعيار اللاسلكي: 5.0
مسافة الإرسال: 10 أمتار
إنتاج الطاقة: 10وات * 2 + 35وات
وقت اللعب: 4 ~ 5 ساعة
تأثير التردد: 100 هرتز - 10 كيلو هرتز
مكبر الصوت: 57mm*2, 4Ω 10W; 90mm, 4Ω 35W
مدخلات الطاقة: 5فولت - 2 أمبير
الحد الأقصى للاستهلاك الحالي: 1 أمبير
نوع البطارية: Li-ion18650
قدرة البطارية: 6000 ملي أمبير
تصنيف القدرة: 3000 ملي أمبير
تصنيف القدرة: واجهة إدخال إشارة الصوت:
مقيس سماعة رأس قياسي Ø3.5 مم (ستيريو)

سمات:

1. اتصال لاسلكي

2. وظيفة الذاكرة

3. دعم القرص U / بطاقة TF / وضع اللعب AUX

4. بطارية ليثيوم مدمجة

5. دعم تسقيع الموسيقى MP3 / WAV / WMA / FLAC / APE

6. استخدام مكبرات الصوت عالية الدقة ، وجعل الصوت أكثر طبيعية وحساسة

7. 1 + 1 دالة تسلسلية

8. مقاومة الماء IPX5

9. وظيفة الطاقة المتحركة: 5فولت ، 1أمبير

POWEROLOGY

باورولوجي فانتوم

تعليمات السماعات اللاسلكية

CE RoHS 100% Made in China

دليل الاستخدام
MODEL: POWPHANSPK