POWEROLOGY

USER MANUAL

SMART DUAL COMPARTMENT
FREIDGE AND FREEZER

PDFOF100.BLD

SAFETY INSTRUCTIONS

WARNING!

- Do not operate the appliance if it is visibly damaged.
- Do not block the gaps of the fridge with things like pin, wire, etc.
- Do not expose the appliance to rain or water. It is water resistant. Operate the appliance near naked flames or other heat sources (heaters, direct sunlight, gas ovens etc).
- Do not store any explosive substances like spray cans with a flammable propellant.
- Ensure the supply cord is dry and not trapped or damaged. Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.
- Do not touch the supply cord with wet hands. Disconnect the supply cord if the energy supply. The appliance is only to be used with the power supply unit provided with the appliance.
- Do not use electrical appliances inside the food storage compartments of the appliance.
- Do not use the appliance outside of its intended use.
- Once unpacked and before turning on, the appliance must be placed on a level surface for more than 6 hours.
- Make sure that the appliance stays horizontally when it is running. The tilt angle must be less than 7° for long time running and be less than 45° for short time running.
- Keep the appliance stable on the ground or in the car. Do not drain upside down.
- Keep the appliance stable on the ground or in the car. Do not drain upside down.

CAUTION!

- Repairs may only be carried out by qualified personnel. Incorrect repair may cause danger.
- The installation of the appliance must be carried out by qualified electrical personnel.
- The installation of DC power in the boat must be handled by qualified electricians.
- The appliance can only use our dedicated rechargeable batteries, non-rechargeable batteries or external power supplies provided by us. Do not use other power sources.
- In use or during storage, Battery found there has been high fever, leakage, odor, distortion and other anomalies, please stop using it immediately and stay away from the battery.
- Battery and of life should be immediately removed from the equipment, please properly handle security of spent batteries, do not put into fire or water.
- Do not modify the power cord or the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they've been given supervision or instructions concerning use of the device in a safe way and understand the hazards.

NOTICE!

- Disconnect the power supply before each cleaning and maintenance and after every use.
- Do not use sharp tools to defrost. Do not damage the refrigerant circuit.
- Risk of child entrapment. Before you throw away your old refrigerator or freezer take off the doors leave the shelves in place so that children may not easily climb inside.
- Check if the cooling capacity of the appliance is suitable for storing the food or medicine. Food may only be stored in its original packaging or in suitable containers.
- If the appliance is left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mold from forming inside the appliance.
- The appliance is intended to be used in household and similar applications such as:
- Staff kitchen areas in shops, offices and other working environments;
- Farm houses and holiday homes; Hotels, motels and other residential environments;
- Bed and breakfast type environments.
- Catering and similar non-retail applications.

Please read the instructions carefully before using. In this manual reflect the most current available at the time of publication, we subject to change without prior notice.

Please according to local regulations regarding disposal of the appliance for its flammable refrigerant and blowing gas.

PRODUCT FEATURES

- High-efficiency DC compressor and conversion module.
- CFC free and great heat insulation.
- Refrigerator: 0°C/32°F~10°C/50°F room temperature).
- Intelligent battery protection system prevents your vehicle from running out of battery.
- LED display control panel for temperature setting, USB charging port, 5V/3A, battery voltage and temperature display.
- Specific parts: interior drain plug, oversized wheels and telescoping handle, cupholder door, interior LED light, cutting board, bottle opener.

PRODUCT STRUCTURE



Note: there are buttons on both sides of the telescoping hand, press them at the same time to pull the rod. The cutting board can be moved by turning the knob on the top cover, it is suggested to clean and dry it after every use.

REVERSE DOOR OPENING DIRECTION

The door opening direction can be changed according to actual needs, please follow the instructions below:

Door Disassembly:



Open the door at a 90° angle

Take off the door from one side

Take off the door from the other side

Door Installation:



Reverse the door opening direction

Align the door shaft with the hole on one side and insert it

Fix the door on the other side, installation finished

FUNCTION AND OPERATION

Note: the right compartment is on the side where the compressor is.

- Power supply: connect to DC 12v/24v or AC 100-240v(using dedicated adapter) or solar (12-50V) power supply.
- Display Screen Installation: when the fridge is powered on, the buzzer will make a long beep, and the display will be on for two seconds then enter the standby mode.
- Power ON/OFF: press ⏻ to switch ON, long press ⏻ for three seconds to switch OFF.
- Temperature Setting:under the running state, long press ⏻ and ⏻ at the same time for three seconds to switch ON/OFF the left compartment, long press ⏻ and ⏻ at the same time for three seconds to switch ON/OFF the right compartment, two compartments cannot be switched off at the same time.
When both left and right compartments are set in running state, press ⏻ or ⏻ to enter left compartment or right compartment, press ⏻ or ⏻ to adjust the temperature, press ⏻ to switch temperature unit (Celsius or Fahrenheit).
Specific parts: interior drain plug, oversized wheels and telescoping handle, cupholder door, interior LED light, cutting board, bottle opener.

- Cooling Mode: under the running state, press ⏻ to switch MAX(fast cooling) and ECO (Energy saving Mode),(Factory setting is MAX)

- Battery Protection Mode: There is a low voltage protection mode to prevent your vehicle from running out of battery. The voltage reference is as follow:

Voltage Reference:

INPUT	DC 12V		DC 24V	
MODE	CUT OUT	CUT IN	CUT OUT	CUT IN
L	11.5V	12.9V	21.3V	22.7V

* the voltage is theoretical value, there may be a deviation in different sceneries.

- Temperature Unit Setting: switch off the fridge, long press ⏻ for 3 seconds until displays ①, and switch to ② by pressing ⏻ again, then press ⏻ or ⏻ to switch Celsius or Fahrenheit. (Factory setting is °C)
- Reset : switch off the fridge, long press ⏻ for 3 seconds until displays ①, under ② mode, long press ⏻ at the same time for seconds to reset the settings.

- Recommended temperature for common food:

Drinks	Fruits	Vegetable	Delicatessen	Wine	Ice cream	Meat
0°C/4°F~8°C/46.4°F	3~10°C/37~50°F	4°C/39°F	10°C/50°F	10°C/14°F	-18°C/0°F	-18°C/0°F

BATTERY OPERATION

- Battery ON/OFF: long press the power button on the battery to switch ON/OFF. When the battery is OFF, short press the power button to show current battery.



- Battery charging (for reference only):



Model: FSAK-002
Battery Capacity:100Wh
Rated Voltage:11.1V
Charging Limited Voltage(DC): 12.6V
Charging Limited Current(DC): 3A

1: Power Indicator (Green charging, Blue discharging)
2: Battery Indicator (show current battery)
3: Power Button
4: DC Charging Port

Warning: do not disassemble the battery!

Wall outlet AC 100~240V (using dedicated adapter)
(Charging time:8h)

Solar panel (charge tighter DC 12/24V)
(When the input voltage<15V, Charging time:8h)

(Connect to the "SOLAR" port of the refrigerator) Solar panel (charge tighter DC 12/24V)
(Charging time:8h)

Battery charger (optional)

(Connect to the DC charging port of the battery)
① Charging time:8h)
② Charging station (optional)
Charging time of a single battery:4~6h)

Note: It is suggested to switch off the refrigerator when charging the battery (the power supply may mainly power the compressor when the refrigerator is running).

When connect to a solar panel, please place the refrigerator in a cool place to dissipate heat. The charging input power should be higher than the working power of the refrigerator(about 40~60W), or switch off the refrigerator, otherwise the battery will run out.

It is suggested to use 100W solar panel.
MAX Solar Input Voltage: 50V, MAX Solar Input Current:10A.

Note: the output of the solar panel is unstable, so it cannot power the refrigerator directly.
Write down the battery voltage every half an hour.

- Discharging time (for reference only): In the low battery protection mode, the battery can last about 4 hours after being fully charged. When the temperature of the refrigerator is set to -18°C/0°F, the ambient temperature is 25°C, it can last 13 hours after the refrigerator temperature stabilizes. Remove or switch off the battery to prevent self-discharge when not in use.

CARE AND MAINTENANCE

Cleaning:

- Switch off and unplug the device first to avoid electric shock.
- Remove the cover and drain from the hole at the bottom of the device.
- Use a soft cloth or sponge to wipe the device.
- Do not soak the fridge in water and do not wash it directly.
- Do not use abrasive cleaning agents during cleaning as these can damage the device.

Storage:

If the device will not be in use for a long time, please follow the instruction:
- Take out all the items stored in the device.
- Take out all the items stored in the device.
- Wipe off the dust.
- Wipe off the defrosted water.
- Leave the lid slightly open to prevent odors from forming.
- Recommended storage environment:
ambient temperature: 25°C, ambient humidity: ≤ 75%

Defrosting:

Humidity can form frost in the interior of the cooling device or on the evaporator. This reduces the cooling capacity. Defrost the device in good time to avoid this.
- Switch off and unplug the device first to avoid electric shock.
- Take out all the items stored in the device.
- Wipe off the dust.
- Wipe off the defrosted water.

Never use hard or pointed tools to remove ice or to loosen objects which have frozen in place.

TROUBLESHOOTING

Issues	Cause/Suggestions
Refrigerator does not work	- Check if the switch is on. - Check if the plug and socket are connected. - Check if the fuse has been burnt. - Check if the power supply is malfunctioned. - Switch on/off the fridge frequently may cause start delay of the compressor
Refrigerator compartments are too warm	- The door is opened frequently. - The door seal is not tight enough. The food was stored recently. - The refrigerator has been disconnected for a long time.
Food is frozen	- The temperature was set too low.
There is "water flow" inside the "Inside-the-refrigerator"	- It's a normal phenomenon, caused by the flow of refrigerant.
There are water/drops around the refrigerator casing or door gap	- It's a normal phenomenon, the moisture will condense to water when it touches a cold surface of the refrigerator.
The compressor is slightly noisy when starting	- It's a normal phenomenon, the noise will be reduced after the compressor works stably.
Code F1 displayed	- Possible cause: low voltage to fridge. - Adjust the battery protection from High to Medium or from Medium to Low
Code F2 displayed	- Possible cause: condenser fan is overloaded. - Disconnect power for fridge for 3 minutes & re-start. If the code shows again, contact manufacturer for service.
Code F3 displayed	- Possible cause: the compressor starts too frequently. - Disconnect power for fridge for 3 minutes & re-start. If the code shows again, contact manufacturer for service.
Code F4 displayed	- Possible cause: compressor not locking, in - Disconnect power for fridge for 3 minutes & re-start. If the code shows again, contact manufacturer for service.
Code F5 displayed	- Possible cause: overheating of the compressor & electronics. - Disconnect power for fridge for 3 minutes & re-start. If the code shows again, contact manufacturer for service.
Code F6 displayed	- Possible cause: no parameter can be detected by the controller. - Disconnect power for fridge for 3 minutes & re-start. If the code shows again, contact manufacturer for service.
Code F7 or F8 displayed	- Possible cause: temperature sensor is faulty. - Contact manufacturer for service.

*For models with FSAK-002 detachable battery, if code F1 displayed, unplug or turn off the battery or connect to DC12/24V/AC100-240V(using the adapter) power supply to power the compressor and battery in time to avoid long-term micro-current charging the battery .

TECHNICAL INFORMATION

MODEL	XPOPDSLBB
RATED VOLTAGE	DC12/24V or AC100~240V(using dedicated adapter) or Solar(12~50V)
RATED POWER	60W
CAPACITY	55.5L/ 36Liq.ft.
NOISE	≤45dB
TEMPERATURE SETTING RANGE	-20~20°C (-4~68°F)
CLIMATE CATEGORY	T/ST/N/SN
DIMENSIONS(L*W*H)	717*460*575mm 28.7*18.1*22.1(inch)
NET WEIGHT	19.5kg(42.1lb) (not including battery)

*Due to product improvement, the technical information might be different from actual information, please refer to the listing label on the product.

11.Tuya APP Connection

1. How to download:
Download Tuya APP or Powerology APP on Google Store(for android) or App Store(for apple).

2. How to connect:
- Turn on the Bluetooth, Location and WIFI of your mobile device(must be connected to 2.4G WIFI network).
- Open POWEROLOGY APP and Add Device, choose the same network, confirm to connect.

3. Main Interface:

Note:
Press the lock icon on the APP to lock/unlock the control panel on the fridge, if locked, the fridge can only be controlled by the APP.

4. How to unbind:
Switch off the fridge, long press ⏻ and ⏻ on the fridge panel at the same time for three seconds to unbind the fridge.

App Store
Google Play

Please contact us through
hey@powerology.me or on our social media platforms.

RoHS

powerology | powerology.me
hey@powerology.me | www.powerology.me

المعلومات الإضافية

الطراز	PFOFSLBB
الجهد	12/24V DC (باستخدام محول مخصص) أو طاقة شمسية (12 ~ 50 فولت)
القوة المصنفة	60 واط
السعة	55.5 لتر / 36 قدماً مكعباً.
الضوضاء	≤45 ديسيبل
درجة الحرارة ضمن الإعداد	-20 ~ 20°C درجة مئوية (-4 ~ 68°F درجة فهرنهايت)
فئة المناخ	T/ST/N/SN
الأبعاد (L*W*H)	717*460*575mm 28.7*18.1*22.1(inch)
الوزن الصافي	19.5 كجم / 42.1 رطل (بدون بطاريات)

بسبب تحسين المنتج، قد يختلف المعلومات الفنية عن المعلومات الفعلية المعلومات، يرجى الرجوع إلى شكل المنتج على الملصق.

اتصال بتطبيق توي

1. تحميل التطبيق:
قم بتنزيل وتثبيت Tuya أو Powerology APP من متجر Google لنظام Android أو App Store لأجهزة Apple.

2. كيفية التوصيل:
- قم بتشغيل Bluetooth والموقع و WIFI لجهازك المحمول، يجب أن يكون متصل بشبكة 2.4G WIFI.
- افتح POWEROLOGY APP وأضف جهاز، وقارن متصل للشبكة، وأكد التوصيل.

3. الواجهة الرئيسية:

ملاحظة:
قفل زر على التطبيق يمكنك / إلغاء قفل لوحة التحكم في الثلاجة ، إذا كانت مقفلة ، لا يمكن التحكم في الثلاجة إلا عن طريق التطبيق.

4. كيفية فك الربط:
أوقاف تشغيل، ثم اضغط على الثلاثة في نفس الوقت لمدة ثلاث ثوان، فك الثلاجة.

App Store
Google Play

يمكن الاتصال بنا من خلال
hey@powerology.me أو على منصات وسائل التواصل الاجتماعي الخاصة بنا

RoHS

powerology | powerology.me
hey@powerology.me | www.powerology.me

استكشاف الأخطاء وإصلاحها

أعطال	السبب / الاقتراحات
الثلاجة لا يعمل	- تحقق من أن المقبس قيد التشغيل. - تحقق من توصيل القابس والمقبس بشكل جيد. - تحقق من أن الفيوز لم يتم حرقه. - تحقق من أن مزود الطاقة يعمل بشكل جيد. - قد يؤدي تشغيل / إيقاف تشغيل الثلاجة بشكل متكرر إلى تأخير بدء تشغيل الضاغط
الثلاجة لا يعمل	- يفتح الباب بشكل متكرر. - ختم الباب ليس محكمًا. تم تخزين الطعام مؤخرًا. - الثلاجة قد تم فصلها لفترة طويلة.
الطعام قد يجمد	- يتم ضبط درجة الحرارة على درجة منخفضة للغاية
"تدفق الماء" داخل الثلاجة	- هذه ظاهرة طبيعية، تنتج عن تدفق مبرد.
ماء / قطرات حول غلاف الثلاجة أو فجوة الباب	- هذه ظاهرة طبيعية، عندما يلامس سطح الثلاجة البارد، سيتكثف الرطوبة إلى ماء.
الضاغط يصدر ضوضاء أعلى عند البدء تشغيل	- هذه ظاهرة طبيعية، سيتم تقليل الضوضاء بعد أن يعمل الضاغط بشكل مستقر.
رمز خطأ F1	- السبب المحتمل: انخفاض الجهد الكهربائي للثلاجة - ضبط حماية البطارية من "متوسط" أو من "منخفض" إلى "متوسط"
رمز خطأ F2	- السبب المحتمل: ارتفاع درجة حرارة المبرد. - قم بفصل الثلاجة لمدة 3 دقائق وإعادة تشغيلها. إذا ظهر الخطأ مرة أخرى، فيرجى مكالمة الشركة المصنعة للخدمة.
رمز خطأ F3	- السبب المحتمل: بدء تشغيل الضاغط بشكل متكرر. - قم بفصل الثلاجة لمدة 3 دقائق وإعادة تشغيلها. إذا ظهر الخطأ مرة أخرى، فيرجى مكالمة الشركة المصنعة للخدمة.
رمز خطأ F4	- السبب المحتمل: الضاغط لا يعمل. - قم بفصل الثلاجة لمدة 3 دقائق وإعادة تشغيلها. إذا ظهر الخطأ مرة أخرى، فيرجى مكالمة الشركة المصنعة للخدمة.
رمز خطأ F5	- السبب المحتمل: ارتفاع درجة حرارة الضاغط والإلكترونيات. - قم بفصل الثلاجة لمدة 3 دقائق وإعادة تشغيلها. إذا ظهر الخطأ مرة أخرى، فيرجى مكالمة الشركة المصنعة للخدمة.
رمز خطأ F6	- السبب المحتمل: وحدة التحكم لا تستطيع الكشف عن أي معلومات. - قم بفصل الثلاجة لمدة 3 دقائق وإعادة تشغيلها. إذا ظهر الخطأ مرة أخرى، فيرجى مكالمة الشركة المصنعة للخدمة.
رمز خطأ F7 أو F8	- السبب المحتمل: مستشعر درجة الحرارة معيب. - اتصل بالشركة المصنعة للخدمة.

بالنسبة للطرازات المزودة بحزمة قابلة للفصل FSAK-002 ، إذا ظهر رمز الخطأ F1 ، فافصل البطارية أو أوقف تشغيلها، وقم بتوصيله بمصدر طاقة 12 / 24 فولت أو 100 ~ 240 فولت (باستخدام المحول) لضمان الحماية الكافية في الوقت المناسب لتجنب استهلاك التيار الدقيق طويل المدى للبطارية.

FUNCTION AND OPERATION

- شاشة العرض: عندما يكون الثلاجة قيد التشغيل، الجرس سيصدر صوت طويل، ثم الشاشة ستدخل في وضع الاستعداد.
- تشغيل / إيقاف التشغيل: اضغط ⏻ لمدة ثانية واحدة للتشغيل، وطويل لمدة ثلاث ثوانٍ للإيقاف.
- إعداد درجة الحرارة: في وضع التشغيل، اضغط ⏻ و ⏻ في نفس الوقت لمدة ثلاث ثوانٍ لتشغيل / إيقاف تشغيل الحجرة اليسرى، اضغط ⏻ و ⏻ في نفس الوقت لمدة ثلاث ثوانٍ لتشغيل / إيقاف تشغيل الحجرة اليمنى، لا يمكن إيقاف تشغيل كلتا الحجرتين في وقت واحد.
- بعد ضبط كلتا الحجرتين، اضغط ⏻ و ⏻ لضبط درجة الحرارة، اضغط ⏻ لتبديل وحدة درجة الحرارة (سيلسيوس أو فهرنهايت).
- درجة الحرارة الموصى بها لتخزين الطعام:

المشروبات	الفواكه	الخضروات	المعلبات	النبيذ	الآيس كريم	اللحوم
0°C/4°F~8°C/46.4°F	3~10°C/37~50°F	4°C/39°F	10°C/50°F	10°C/14°F	-18°C/0°F	-18°C/0°F

تشغيل البطارية

- تشغيل / إيقاف تشغيل البطارية: اضغط لمدة طويلة زمنية على زر التشغيل المتبوعة بالطاقة لتشغيل / إيقاف تشغيل البطارية.
- شحن البطارية:

- شحن البطارية في الثلاجة (للرجوع فقط)
- شحن البطارية في المحطة (اختياري)
- شحن البطارية في الشاحن (اختياري)

- وضع درجة حرارة الثلاجة أولاً، وضع الوضع "MAX" (التبريد السريع) و ECO (توفير الطاقة) (إعداد المصنع هو MAX).
- وضع حماية البطارية: يتم تطبيق وضع حماية الجهد المنخفض لمنع سيارتك من نفاد البطارية. مرجع الجهد كما يلي:

INPUT	DC 12V		DC 24V	
MODE	CUT OUT	CUT IN	CUT OUT	CUT IN
L	11.5V	12.9V	21.3V	22.7V

الجهد هو قيمة النظرية ، قد يكون هناك انحراف في مشاهد مختلفة.

FUNCTION AND OPERATION

- شاشة العرض: عندما يكون الثلاجة قيد التشغيل، الجرس سيصدر صوت طويل، ثم الشاشة ستدخل في وضع الاستعداد.
- تشغيل / إيقاف التشغيل: اضغط ⏻ لمدة ثانية واحدة للتشغيل، وطويل لمدة ثلاث ثوانٍ للإيقاف.
- إعداد درجة الحرارة: في وضع التشغيل، اضغط ⏻ و ⏻ في نفس الوقت لمدة ثلاث ثوانٍ لتشغيل / إيقاف تشغيل الحجرة اليسرى، اضغط ⏻ و ⏻ في نفس الوقت لمدة ثلاث ثوانٍ لتشغيل / إيقاف تشغيل الحجرة اليمنى، لا يمكن إيقاف تشغيل كلتا الحجرتين في وقت واحد.
- بعد ضبط كلتا الحجرتين، اضغط ⏻ و ⏻ لضبط درجة الحرارة، اضغط ⏻ لتبديل وحدة درجة الحرارة (سيلسيوس أو فهرنهايت).
- درجة الحرارة الموصى بها لتخزين الطعام:

المشروبات	الفواكه	الخضروات	المعلبات	النبيذ	الآيس كريم	اللحوم
0°C/4°F~8°C/46.4°F	3~10°C/37~50°F	4°C/39°F	10°C/50°F	10°C/14°F	-18°C/0°F	-18°C/0°F

تشغيل البطارية

- تشغيل / إيقاف تشغيل البطارية: اضغط لمدة طويلة زمنية على زر التشغيل المتبوعة بالطاقة لتشغيل / إيقاف تشغيل البطارية.
- شحن البطارية:

- شحن البطارية في الثلاجة (للرجوع فقط)
- شحن البطارية في المحطة (اختياري)
- شحن البطارية في الشاحن (اختياري)

- وضع درجة الحرارة أولاً، وضع الوضع "MAX" (التبريد السريع) و ECO (توفير الطاقة) (إعداد المصنع هو MAX).
- وضع حماية البطارية: يتم تطبيق وضع حماية الجهد المنخفض لمنع سيارتك من نفاد البطارية. مرجع الجهد كما يلي:

INPUT	DC 12V		DC 24V	
MODE	CUT OUT	CUT IN	CUT OUT	CUT IN
L	11.5V	12.9V	21.3V	22.7V

الجهد هو قيمة النظرية ، قد يكون هناك انحراف في مشاهد مختلفة.

عكس اتجاه فتح الباب

يمكن وفقا لحاجة فتح الباب وفقا للمتطلبات الفعلية ، يمكن اتباع التعليمات أدناه:

يفكك الباب:

افتح الباب بزاوية 90 درجة

انزع الباب من جانب واحد

انزع الباب من الجهة الأخرى

يركب الباب:

اعكس اتجاه فتح الباب

قم بمحاذاة عمود الباب مع الثقب على جانب واحد وإدراجه

قم بتثبيت الباب، التثبيت مكتمل

تعليمات السلامة

تحذير!

- لا تقم بتشغيل الجهاز إذا كان تالفًا بشكل مرئي.
- لا تسد الفجوات الموجودة في الثلاجة بأشياء مثل الدبابيس والأسلاك وما إلى ذلك.
- لا تعرض الجهاز للمطر أو الماء. إنه مقاوم للماء. قم بتشغيل الجهاز بالقرب من اللهب المكشوف، مصادر الحرارة الأخرى (السخانات، ضوء الشمس المباشر، أفران الغاز وما إلى ذلك).
- لا تخزن أي مواد متفجرة مثل علب الرش التي يحتوي على مادة دافعة قابلة للاشتعال.
- تأكد من أن سلك طاقة الجهاز جاف وغير محشور أو تالف. لا تقم بتوصيل أو تقع في وضع خلفي عدة مقبوس مقبس قابل للنقل أو مزودات الطاقة المحمولة.
- لا تلمس سلك الطاقة بيدين مبتلتين. إذا كان الجهاز يعمل بالطاقة، افصل الطاقة. يجب أن يكون الجهاز مزودًا بوحدة الطاقة المزودة بالجهاز.
- لا تستخدم الأجهزة الكهربائية داخل حجرات تخزين الطعام للجهاز.
- لا تستخدم الجهاز خارج الاستخدام المقصود.
- بمجرد إزالته من العبوة وقبل التشغيل، يجب وضع الجهاز على سطح مستوٍ لأكثر من 6 ساعات.
- تأكد من أن الجهاز يعمل أفقيًا أثناء التشغيل. يجب أن تكون زاوية الميل أقل من 7 درجات لفترة طويلة وأقل من 45 درجة لفترة قصيرة.
- حافظ على جهازك مستقرًا على الأرض أو في الشاحنة. لا تقم بالصرف رأسًا على عقب.
- حافظ على جهازك مستقرًا على الأرض أو في الشاحنة. لا تقم بالصرف رأسًا على عقب.

تنبيه!

- قم بفصل الجهاز عن الطاقة قبل كل تنظيف وصيانة وبعد كل استخدام.
- لا تستخدم أدوات حادة لإزالة الجليد. لا تلحق الضرر بالدائرة المبردة.
- خطر احتجاز الأطفال. قبل أن تتخلص من الثلاجة القديمة أو الفريزر، قم بإزالة الأبواب واترك الرفوف في مكانها حتى لا يتمكن الأطفال من التسلق بسهولة بداخلها.
- تحقق من أن سعة التبريد للجهاز مناسبة لتخزين الطعام أو الأدوية. يجب تخزين الطعام فقط في عبواته الأصلية أو في حاويات مناسبة.
- إذا كان الجهاز فارغًا لفترات طويلة، قم بإيقاف تشغيله، وإزالة الجليد، والتنظيف، والتجفيف، وترك الباب مفتوحًا لمنع تكون العفن داخل الجهاز.
- الجهاز مخصص للاستخدام في التطبيقات المنزلية وما شابهها مثل:
- مناطق المطبخ الخاصة بالموظفين في المتاجر والمكاتب وبيئات العمل الأخرى؛
- المزارع والمنازل الريفية؛ الفنادق والموتيلات وغيرها من البيئات السكنية؛
- بيئات الإقامة والإفطار.
- الخدمات الغذائية وما شابهها غير البيع بالتجزئة.

اقرأ التعليمات بعناية قبل الاستخدام. في هذا الدليل، تعكس أحدث المعلومات المتاحة وقت النشر، قد يخضع للتغيير دون إشعار مسبق.

تحذير!

- لا يجوز إجراء الإصلاحات إلا من قبل موظفين مؤهلين. قد يسبب الإصلاح غير الصحيح في حدوث خطر.
- يجب تنفيذ التصميم في الشبكة بت في يوم بواسطة المهندسين المؤهلين.
- يجب تركيب طاقة التيار المستمر في القارب بواسطة الفنيين المؤهلين.
- يمكن للجهاز فقط استخدام بطارياتنا المخصصة القابلة للشحن، غير القابلة للشحن، أو مزودات الطاقة الخارجية التي نوفرها. لا تستخدم مصادر طاقة أخرى.
- أثناء الاستخدام أو التخزين، البطارية الموجودة هناك بحرارة شديدة، وتشويه، وتشويه، وغيرها من الشذوذ، يرجى التوقف عن استخدامها على الفور، وتجنب البطارية.
- يجب إزالة بطارية وعمر البطارية من الجهاز، ويرجى التخلص من النفايات بشكل صحيح، ولا تضعها في النار أو الماء.
- لا تقم بتعديل سلك الطاقة أو الجهاز. يجب عدم قيام الأطفال بالتنظيف والصيانة الخاصة بالمستخدم بدون إشراف.
- يمكن استخدام الجهاز من قبل الأطفال الذين يبلغون من العمر 8 سنوات وما فوق والأشخاص الذين لديهم قدرات جسدية أو حسية أو عقلية مخفضة أو نقص في الخبرة والمعرفة إذا تم إعطاؤهم الإشراف أو التعليمات المتعلقة بكيفية استخدام الجهاز بطريقة آمنة وفهمهم للمخاطر.

تنويه!

- افصل الجهاز الطاقة قبل كل تنظيف وصيانة وبعد كل استخدام.
- لا تستخدم أدوات حادة لإزالة الجليد. لا تلحق الضرر بالدائرة المبردة.

دليل المستخدم

مضخوة مزدوجة ذكية
ثلاجة ومجمد

PDFOF100.BLD