



Powerology

FLUKS 4-IN-1 Multifunction Vacuum


SKU: PWVC013BK

Product Introduction

The Powerology FLUKS 4-IN-1 Multifunction Vacuum & Blower is a cordless cleaner for home and vehicle use. Interchangeable accessories support suction, blowing, inflation and air pumping; the digital display shows battery and operating status.


Structural Diagram

The FLUKS has a removable dust bin, washable dual-filter system, digital controls, air intakes, an air outlet and USB-C charging.



Package Contents Overview

Supplied attachments support surface cleaning, confined spaces, blowing, inflation and air pumping.



1. Main body
2. 2-in-1 long nozzle
3. Brush
4. Small floor brush
5. Ripple hose suction nozzle
6. USB-C charging cable
7. Large nozzle
8. Medium nozzle
9. Trumpet nozzle
10. Small brush

Package Contents

1. FLUKS 4-IN-1 Multifunction Vacuum × 1
2. 2-in-1 long nozzle × 1
3. Brush × 1
4. Small floor brush × 1
5. Ripple hose suction nozzle × 1
6. USB-C charging cable × 1
7. Large nozzle × 1
8. Medium nozzle × 1
9. Trumpet nozzle × 1
10. Small brush × 1

Safety Instructions

Warning:

1. Do not immerse the appliance or use it to collect water or wet materials.
2. Do not collect burning, smoking, combustible, or explosive materials.

3. Keep the air inlet, air outlet, hair, loose clothing, and fingers apart during operation.
4. Do not collect sharp or hard objects that could damage the appliance.
5. Do not cover or obstruct the air inlet or air outlet.
6. Do not modify, disassemble, crush, puncture, or incinerate the appliance or battery.
7. Stop using the appliance if it is damaged, overheats, emits an unusual odor or noise, leaks, or malfunctions.
8. Charge only with a certified USB adapter and cable matching the rated 5 V/2 A input.
9. Keep the appliance and its accessories out of reach of children.
10. Keep the appliance away from heat sources, flames, flammable vapors, and direct sunlight.
11. Operate, store and charge the product only within the temperature ranges specified on the product labeling or by the manufacturer.
12. Switch off the product before charging and do not operate it while charging.
13. Charge only indoors in a dry area; do not use a damaged cable, connector, USB power source or charging port.
14. If the product stops because of a battery-protection condition, switch it off, disconnect it from charging and allow it to cool before retrying; discontinue use if the condition recurs.
15. This product contains a built-in lithium battery; dispose of the product through applicable local battery or e-waste collection and recycling facilities, and do not remove the battery yourself.

Attention:

1. Read and retain these instructions before use.
2. Switch off the appliance before installing, removing, or cleaning accessories.
3. Install the HEPA filter before collecting dust or debris.
4. Empty the dust cup and clear blocked air passages when the full indicator appears or suction decreases.
5. Allow the metal filter and HEPA filter to dry completely before reinstalling them.

6. Clean the appliance with a slightly damp cloth and do not allow moisture to enter the motor.
7. Store the appliance in a cool, dry, low-dust place when not in use.
8. Place the appliance on a stable, flat surface while charging.

Charging and Operation

1. Charge the FLUKS vacuum & blower:

Place the product on a stable, flat surface in a dry indoor area.

Switch off the product before charging. Do not operate it while charging.

Inspect the USB-C cable, charging port, connector and USB power source. Do not charge if any part is damaged.

Insert the USB-C charging cable into the charging port.

Connect the USB-A end to a suitable 5 V/2 A USB power source. An adapter is not included.

The battery icon flashes and its level increases while charging.

The battery icon remains illuminated when fully charged.

2. Power On, Select a Speed and Power Off:

Fully charge the battery before first use.

Install the appropriate attachment.

Press and hold the power button for 3 seconds to turn on the Vacuum.

While running, short-press the power button to switch between first and second gear.

Press and hold the power button for 3 seconds to turn off the product.

3. Use the Suction Function:

Turn off the product before fitting or replacing an attachment.

Confirm the HEPA filter and metal filter screen are correctly installed in the dust bin.

Fit the appropriate nozzle or brush to the suction inlet.

Turn on the product and select the required speed.

Guide the attachment over the area without covering the air inlet or outlet.

4. Use the 2-in-1 Long Nozzle and Brush:

Use the long nozzle to remove dust from gaps in vehicle doors, seats, cabinet corners, drawers, ashtrays and sofas.

Fit the brush for cushions, suede sections of foot mats, keyboards and air-conditioning outlets.

Turn off the product before changing between nozzle and brush configurations.

Turn on the product and guide the attachment gently over the cleaning area.

5. Use the Ripple Hose Suction Nozzle:

Turn off the product and connect the ripple hose suction nozzle.

Bend or twist the flexible hose to reach confined or awkward areas.

Connect a suitable nozzle to the hose end when needed.

Turn on the product and clean the target area without sharply crushing or obstructing the hose.

6. Use the Blowing Function:

Turn off the product before installing the blowing attachment.

Connect the appropriate nozzle to the air outlet.

Aim the nozzle at the target area.

Turn on the product and select the required speed.

Keep the air inlet and outlet unobstructed during operation.

7. Inflate an Item:

Select an attachment that fits the inflation valve.

Connect the attachment to the air outlet, then to the valve.

Turn on the product and monitor the item as it inflates.

Turn off the product when the required inflation level is reached.

Disconnect the attachment and close the item's valve.

8. Pump Air from a Storage Bag:

Select the nozzle that fits the vacuum storage bag valve.

Confirm the filters are installed, then connect the nozzle to the suction side.

Hold the nozzle securely against the valve and turn on the product.

Monitor the bag and turn off the product when sufficient air is removed.

Remove the nozzle and seal the valve.

9. Respond to Display Indicators:

If the low-battery icon flashes five times before shutdown, recharge the product.

If the trash-can icon illuminates and the display flashes five times before shutdown, turn off the product.

Empty the dust bin and inspect the air inlet for blockage.

After clearing the obstruction and correctly reinstalling the filters and dust bin, turn on the product again.

Specifications

Motor Type	- Brushless DC Motor
Motor Model	- BLDC-VKT45128
Power	- 43W / 65W / 100W / 130W
Max Power	- 130W
Motor Speed	- 57,000 / 78,000 / 110,000 RPM
Speed Levels	- 3 Levels
Motor Working Current	- Approx. 3.5A / 7.6A / 9.8A
Suction	- 10 / 13.5 / 21kPa
Max Suction	- 21kPa
Air Volume	- 22 / 30 / 40 Nm ³ /h
Blowing Force	- 45 / 60 / 85g
Battery Capacity	- 2600mAh
Battery Voltage	- 10.8V
Battery Energy	- 28.08Wh
Battery Configuration	- 18650, 3S1P
Charging Input	- 5V/2A
Charging Port	- USB-C
Charging Time	- 3.5 Hours
Working Time	- 32 / 18 Min
Dust Bin Capacity	- 180mL
Filter System	- PET + Metal Filter
Filter Material	- F6 Composite PET
Filter Efficiency	- ≥95% at 0.3μm
Noise Level	- ≤80dB
Motor Life	- ≥500 Hrs
Operating Temperature	- 0°C to 40°C
Storage Temperature	- -20°C to 60°C
Charging Cable Length	- 80cm
Product Weight	- 512g
Product Size	- 33 x 6.7 x 5.2cm
Model Number	- PWVC013

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our Powerology website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our Powerology website or store. If Powerology products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty,

visit our website www.powerology.me/warranty and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check: www.powerology.me/warranty

Contact Us

Email: hey@powerology.me

Website: www.powerology.me

Instagram: [powerology_official](https://www.instagram.com/powerology_official)

Facebook: [powerology.ME](https://www.facebook.com/powerology.ME)