POWEROLOGY

Works with Apple Find My

POWEROLOGY

Powerology

POWEROLOGY ARCTAG

Find My Smart Tag

SKU: PWF19BK

Package Contents

1. POWEROLOGY ARCTAG Find My Smart Tag × 1

Safety Instructions

Warning:

1. Keep the product and coin cell battery out of reach of children; swallowing can cause severe internal burns or death.
2. Seek immediate medical attention if a battery is swallowed or inserted into any part of the body.
3. Do not recharge, short-circuit, crush, puncture, heat, or burn the battery.
4. Insert the battery with the correct polarity (+ and −). Do not force batteries.
5. Do not use the product if the battery compartment does not close securely.
6. Do not immerse the product in water or expose it to excessive moisture.
7. Keep the product and battery away from fire, heat sources, and flammable or corrosive environments.
8. Do not disassemble, modify, strike, or throw the product.
9. Do not hold the device close to your ears when it is sounding.
10. Use only with the Apple Find My app on a compatible iPhone or iPad signed in to an Apple Account, with Bluetooth, Location Services, required permissions, and an internet connection enabled.
11. The product has no stated water-resistance rating; keep it dry and do not expose it to water beyond accidental minor splashes.
12. Collect and recycle used CR2032 batteries separately where required; do not discard them loose or leave them where children can access or swallow them.

Attention:

1. Follow the setup, operation, and battery-replacement instructions in this manual.
2. Remove an exhausted battery promptly and dispose of it according to local regulations.
3. Remove the battery before storing the product for an extended period.
4. Clean with a soft, dry cloth; do not use abrasive cleaners or solvents.
5. Stop using the product if it becomes unusually hot, damaged, or malfunctions.
6. Keep this manual for future setup, safety, battery-replacement, and disposal reference.



Product Overview

The POWEROLOGY ARCTAG Find My Smart Tag is a compact Bluetooth tracking accessory designed for use with the Apple Find My app to help locate personal essentials. Attach it to keys, bags, or other belongings to locate the item, receive left-behind notifications, play an audible alert, or enable Lost Mode.



Setup and Operation

1. Before You Begin

Use the Apple Find My app with a compatible iPhone or iPad running iOS or iPadOS 14.5 or later.

Sign in to an Apple Account and enable Bluetooth, Location Services, and the required Find My and notification permissions.

Connect the mobile device to the internet using Wi-Fi or cellular data for setup and location-related features.

2. Install the Battery

Open the battery compartment carefully.

Insert a CR2032 battery, observing the polarity markings inside the compartment.

Close the battery compartment securely.

Press the button to confirm that the POWEROLOGY ARCTAG Find My Smart Tag is responsive.

3. Pair the Smart Tag

Enable Bluetooth on your compatible mobile device.

Open the Apple Find My app.

Keep the POWEROLOGY ARCTAG Find My Smart Tag close to the mobile device.

Press the button and follow the in-app instructions to add the smart tag.

Assign an item name and complete the setup process.

4. Attach the Smart Tag

Pass a suitable key ring or attachment through the integrated loop.

Secure the POWEROLOGY ARCTAG Find My Smart Tag to keys, luggage, a bag, or another personal belonging.

Confirm that the attachment is closed and cannot detach during normal use.

5. Locate a Nearby Item

Open the Apple Find My app on the paired mobile device.

Select the POWEROLOGY ARCTAG Find My Smart Tag from the item list.

Use the app command to play an audible alert.

Follow the sound to locate the attached item.

6. Use Lost Mode

Open the Apple Find My app and select the POWEROLOGY ARCTAG Find My Smart Tag.

Enable Lost Mode when the attached item cannot be found nearby.

Follow the prompts in the app to complete the Lost Mode settings.

Disable Lost Mode after the item has been recovered.

7. Use Left-Behind Notifications

Open the settings for the POWEROLOGY ARCTAG Find My Smart Tag in the Apple Find My app.

Enable left-behind notifications.

Review any available location exceptions within the app.

Respond to an alert by checking that the tagged item is still with you.

Instructions for device button

1. Power on the device Press the button For three seconds, the device will make a sound, and the device will turn on.
2. Device Status customization: Double-click the device button, the device makes a beep sound, indicating that the device is working. If it does not ring, the device is not powered on. Press the button once to turn it on.
3. The device enters the pairing state again After removing the device from the app, the device will beep, will not shut down, and will be in pairing mode. If it is not paired within 3 minutes, the device will leave the pairing state. If you need to pair devices at this point, click the device button once and the device beeps. At this point, thedevice enters the pairing state and can be paired with the app again.

Legal notice

To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technologies identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, Mac, macOS and watchOS are trademarks of Apple Inc. iOS is a trademark or registered trademark of Cisco in the U. S. and other countries and is used under license.

FAQ

1. When can the device be located?

When an item is separated from its owner for a period of time, it can be found by other Apple devices that are part of the Find My network, and the owner can start to get the location of the device.

2.How is the device designed to discourage unwanted tracking?

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

I. If you have an iPhone or iPad, Find My will send notifications to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.

2. If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved These features were created specifically to discourage people from trying to track you without your knowledge.

3.How is my privacy protected?

Only you can see where your item is. Your location data and history are never stored on the item itself. Devices that relay the location of your item also stay anonymous, and that location data is encrypted every step of the way.

4. What is the Find My network? And how does it work?

The Apple Find My network provides an easy, secure way to locate compatible personal items on a map using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch. Simply pair your compatible product with the Apple Find My app to view it right alongside your Apple devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find My network is encrypted and anonymous, so no one else, not even Apple or the mark of your personal item, can view its location.

Specifications

Compatible OS	iOS 14.5 or Later
Power Source	CR2032 Battery
Operating Voltage	2.0 ~ 3.3V
Connectivity Method	Bluetooth
Standby Time	>12 Months
Alarm Volume	60 ~ 80dB
Product Size	32 × 32 × 8mm
Product Weight	13g
Product Material	ABS + Metal Trim
Model Number	PWF19

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our Powerology website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our Powerology website or store. If Powerology products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website www.powerology.me/warranty and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check: www.powerology.me/warranty

Contact Us

Email:**hey@powerology.me**

Website: **www.powerology.me**

Instagram: **powerology_official**

Facebook: **powerology.ME**

Powerology

علامة ذكية متوافقة مع Find My

رمز المنتج: PWF19BK

محتويات العبوة

1. POWEROLOGY ARCTAG Find My Smart Tag × 1

تعليمات السلامة

1. لا تستخدم البطارية إذا تلفت أو تآكلت أو تسربت.
2. لا تضع البطارية في الفم أو تبتلعها لتجنب الاختناق.
3. احفظ البطارية بعيدًا عن متناول الأطفال.
4. لا تستخدم البطارية بعد انتهاء صلاحيتها.
5. لا تحاول شحن البطارية غير القابلة للشحن.
6. لا تحاول فتح البطارية أو تعديلها.
7. لا تحرق البطارية أو تعرضها لدرجات حرارة عالية.
8. لا تضع البطارية في الماء أو تعرضها لبيئة رطبة.
9. لا تستخدم البطارية إذا كان الغلاف الخارجي متضررًا.
10. لا تستخدم البطارية إذا كان هناك تسرب أو تغير في اللون.
11. لا تستخدم البطارية إذا كان هناك تسرب أو تغير في اللون.
12. تخلص من البطارية المستعملة بطريقة آمنة وفقًا للوائح المحلية.

نظرة عامة على المنتج

تم تصميم العلامة الذكية Find My Smart Tag من POWEROLOGY ARCTAG لمساعدتك على العثور بسهولة على أغراضك الشخصية باستخدام تطبيق Apple Find My. يمكنك إرفاقه بالمفاتيح أو الحقائب أو الأمتعة أو أي أغراض أخرى مهمة، ثم استخدام التطبيق لتحديد موقعه أو تشغيل تنبيه صوتي. كما يمكنك تفعيل وضع "المفقود" لإرسال إشعار عند العثور عليه.

الإعداد والتشغيل

1. قبل البدء

استخدم تطبيق Find My من Apple على iPhone أو iPad متوافق يعمل بنظام iOS أو iPadOS 14.5 أو إصدار أحدث.

سجل الدخول إلى حساب Apple وقم بتشغيل Bluetooth وخدمات الموقع والأذونات اللازمة، كما أن تشغيل الإنترنت ضروري.

2. تركيب البطارية

افتح حجرة البطارية بعناية.

أدخل بطارية CR2032 مع مراعاة علامات القطبية داخل الحجرة.

أغلق حجرة البطارية بإحكام.

اضغط على الزر للتأكد من استجابة POWEROLOGY ARCTAG Find My Smart Tag

3. إقران العلامة الذكية

قم بتشغيل Bluetooth على جهازك المتصل المتوافق.

افتح تطبيق Apple Find My.

أبقِ POWEROLOGY ARCTAG Find My Smart Tag قريبًا من الجهاز المتصل.

اضغط على الزر واتبع التعليمات داخل التطبيق لإضافة العلامة الذكية.

عيّن اسمًا للعنصر وأكمل عملية الإعداد.

4. تثبيت العلامة الذكية

مرر حلقة مناسبة أو أداة تثبيت عبر الحلقة المدمجة.

ثبّت POWEROLOGY ARCTAG Find My Smart Tag بالمفاتيح أو الأمتعة أو الحقيبة أو أي غرض شخصي آخر.

تأكد من أن الأداة المثبتة مغلقة وتمنع فكها بشكل طبيعي أثناء الاستخدام العادي.

5. تحديد موقع غرض قريب

افتح تطبيق Apple Find My على الجهاز المتصل المقترن.

حدد POWEROLOGY ARCTAG Find My Smart Tag من قائمة الأجهاز.

استخدم أمر التطبيق لتشغيل تنبيه صوتي.

اتبع الصوت لتحديد موقع الغرض المثبّت به الجهاز.

6. استخدام وضع المفقود

افتح تطبيق Apple Find My وحدد POWEROLOGY ARCTAG Find My Smart Tag.

فعّل وضع المفقود عندما يتعذر العثور على العنصر المثبّت به الجهاز في محيطك القريب.

اتبع المطالبات في التطبيق لإكمال إعدادات وضع المفقود.

عطّل وضع المفقود بعد استعادة العنصر.

7. استخدام إشعارات ترك العنصر خلفك

افتح إعدادات POWEROLOGY ARCTAG Find My Smart Tag في تطبيق Apple Find My.

فعّل إشعارات ترك العنصر خلفك.

راجع أي استثناءات للموقع متاحة داخل التطبيق.

استجب للتنبيه بالتحقق من أن العنصر المميّز ما يزال معك.

العناية والصيانة

1. العناية الدورية

امسح السطح الخارجي بقطعة قماش ناعمة وجافة.

حافظ على أن يكون الجهاز نظيفًا وجافًا.

لا تستخدم منظفات كاشطة أو مذيبات أو مواد كيميائية قوية.

من حقنة مطاطية أو أداة لفت مناسبة مع الحفاظ عليه جافًا بقدر الإمكان.

امسح حلقة المفاتيح والمعادن بالتوازي لتأكد من عدم وجود أي تلف.

2. تغيير البطارية

عندما تنخفض البطارية، يُنصح باستبدالها في أقرب وقت ممكن.

افتح حجرة البطارية بعناية.

أزل البطارية المستهلكة وتخلص منها وفقًا للوائح المحلية.

أدخل بطارية CR2032 جديدة مع مراعاة القطبية الصحيحة.

أغلق حجرة البطارية بإحكام.

اضغط على الزر للتأكد من استجابة POWEROLOGY ARCTAG Find My Smart Tag

الأسئلة الشائعة:

1. متى يمكن تحديد موقع العنصر؟

عندما يتم فصل العنصر عن مالكه لفترة من الزمن، يمكن العثور عليه بواسطة أجهزة أخرى تستخدم شبكة Find My، ويمكن للمالك البدء في تحديد موقع الجهاز.

2. كيف صُمم الجهاز لمنع التتبع غير المرغوب فيه؟

إذا رصد أي منتج من منتجات شبكة "العثور على" متصل من مالكه بالقرب منك على مدار الوقت، فستتلقى إخطارات بأحد الطريقتين التاليتين:

1. إذا كان لديك iPhone أو iPad، فسيرسل "العثور على" إشعارات إلى جهاز Apple الخاص بك. هذه الميزة متوفرة على iOS 14.5 أو iPadOS 14.1 أو أحدث.

2. إذا لم يكن لديك جهاز iOS أو هاتف ذكي، فسيصدر منتج شبكة "العثور على" الذي لا يكون مع مالكه لفترة من الزمن صوتًا عند تحريكه. تم تصميم هذه الميزات خصيصًا لمنع محاولة تتبعك دون علمك.

3. كيف تتم حماية خصوصيتي؟

لست فقط من يستطيع رؤية مكان عنصرك. لم يتم تخزين بيانات موقعك وسجلك أبدًا على العنصر نفسه

المواصفات

Model	PWF19
نظام التشغيل المتوافق	iOS 14.5 أو أحدث
مصدر الطاقة	بطارية CR2032
جهد التشغيل	2.0 ~ 3.3V
تقنية الاتصال	Bluetooth
مدة الاستعداد	>12 شهرًا
مستوى صوت التنبيه	60 ~ 80dB
أبعاد المنتج	32 × 32 × 8mm
وزن المنتج	13g
مادة المنتج	ABS + إطار معدني
رقم الطراز	PWF19BK

التخلص من المنتج

يجب عدم التخلص من هذا المنتج مع النفايات المنزلية غير المصنفة. من المهم فصل هذه النفايات للمعالجة وإعادة التدوير بشكل سليم وفقًا للوائح المحلية لإدارة النفايات.

الضمان

تتمتع أجهزة Powerology بضمان لمدة 24 شهرًا على جميع المنتجات التي تشتريها مباشرة من موقع Powerology الإلكتروني أو متجرنا الذي يمتد لمدة 24 شهرًا.

يسري ضمان لمدة 12 شهرًا على جميع المنتجات التي يتم شراؤها بشكل مباشر من موقع Powerology الإلكتروني أو متجرنا أو أي من متاجر التجزئة المعتمدين لدينا. في حال شراء المنتج من أحد متاجر التجزئة المعتمدين لدينا، لا تنطبق الضمان.

تواصل معنا

البريد الإلكتروني: **hey@powerology.me**

الموقع الإلكتروني: **www.powerology.me**

انستغرام: **powerology_official**

فيسبوك: **powerology.ME**