



Powerology

Ultra-Thin 5000mAh MagSafe Power Bank

SKU: PPBCHA63

Table of Contents


Overview	2
Schematic View	2
Specifications	2
Instructions for Use	2
Troubleshooting	3
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6

Overview

This power bank features strong magnets that securely attach to compatible devices for stable charging. It offers efficient heat dissipation to prevent overheating and ensure safe performance. The Type-C in/out port enables fast and versatile charging with dual functionality. With a 0.65cm ultra-thin design, it is compact and highly portable. The aluminum housing provides durable and lightweight protection, while built-in safeguards protect against overcharging and short circuits.

Schematic View

- 1. Magnetic Wireless Charging Area
- 2. Wireless Charging Indicator
- 3. Battery Indicator
- 4. Type-C Interface



Specifications

Capacity	5000mAh
Type-C Input	5V/3A, 9V/2A, 18W
Type-C Output	5V/3A, 9V/2.22A, 12V/1.5A, 20W
Wireless Output	5W, 7.5W, 15W
Weight	103g
Thickness	0.65cm

Instructions for Use

- 1. Connect the built-in Type-C port to store power for the product.

2. Use the built-in Type-C PD output port to charge other mobile devices or connect to a magnetic wireless charger.

Troubleshooting

Problem	Possible Cause	Solution
The product has been charging for a long time, but the LED screen does not indicate full charge.	1. The charging time is insufficient. 2. The charger or the product is malfunctioning.	1. Charge the product for over 5 hours. 2. Contact an authorized service center for assistance.
Unable to view the remaining power level of the product.	1. The remaining power has completely depleted. 2. The power button or indicator light is not functioning. 3. The product has experienced a power failure.	1. Recharge the product. 2. Contact an authorized service center for assistance.
While charging other devices, the product provides power but does not fully charge them.	The product's power has been fully consumed.	Recharge the product again.
The product still holds some charge, but its external power supply use may cause it to stop functioning abruptly and fail to display power levels.	An external short circuit or excessive electrical load has activated the product's automatic protection system.	Recharge the product to activate it.

Safety Precautions

1. Carefully read all instructions before using the product.
2. When using this product for the first time, perform a full charge and discharge cycle to extend its service life.
3. Ensure the device you want to charge is compatible with the power bank's specifications.
4. Keep the power bank out of reach of children, infants, and pets.
5. Avoid dropping or subjecting the power bank to impacts.
6. Do not expose the power bank to water or immerse it in water.
7. **Warning:** If the power bank comes into contact with water, do not use it.
8. Do not puncture or disassemble the power bank. Do not disassemble the product under any circumstances, as this will void the warranty.
9. Never throw the power bank into a fire, as it may cause an explosion.
10. If the power bank malfunctions or is swallowed, stop using it and contact a service center immediately.
11. Do not dispose of the power bank as household waste.
12. Avoid leaving the power bank in a car on hot days. Do not expose the battery to direct sunlight, fire, or extreme heat.
13. Do not use the power bank in environments with high temperatures or humidity.
14. Always monitor the power bank when it is charging other devices or being charged. Never leave it unattended.
15. Disconnect the charger once the battery is fully charged; do not leave it charging for an extended period.
16. Improper battery replacement may result in an explosion. Use only the same or equivalent battery type, and ensure replacement is performed by maintenance personnel, not by unqualified individuals.
17. Improper battery replacement may result in an explosion. Use

only the same or equivalent battery type, and ensure replacement is performed by maintenance personnel, not by unqualified individuals.

18. When using a power adapter for charging, only use a branded certified adapter that complies with standard requirements.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:
powerology.me/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **powerology.me**

Instagram: **[powerology_official](https://www.instagram.com/powerology_official)**

Facebook: **[powerology.ME](https://www.facebook.com/powerology.ME)**