



Powerology

Qi2 Fast Charging Multi-Device Hub


SKU: PWCUQC033

Table of Contents

Schematic View	2
Charging Guide	2
Indicator Guide	2
Compatible Devices	3
Specifications	3
Safety Precautions	4
Disposal	5
Warranty	6
Contact Us	6


Schematic View

1. Phone Charging Area
2. Apple Watch Charging Area
3. Charging Indicator
4. Earbud Charging Area
5. Type-C Port



Charging Guide

1. Connect the power supply to activate the product.
2. Place your phone, earphones, or watch in the designated charging position and ensure it charges properly.



Indicator Guide

1. **Power On:** The light remains on for 5 seconds and then turns off.
2. **Standby Mode:** The light turns off.
3. **Charging Prompt:** The phone indicator light stays on for 5 seconds

and then turns off. The indicator does not turn on for headphones or watches.

4. Hub is Fully Charged: The light turns off.

5. Metal Foreign Object Detection: The phone indicator light flashes (no indicator light if a foreign object is detected on headphones or watches).

Compatible Devices

Note: Plug into 27W or higher power adapter.

1. For smartphones without MagSafe, use an additional magnetic ring or MagSafe case to enable compatibility with this product.

2. When the input voltage is 5V, the device will display a warning light. Due to the low 5V voltage, high power demand during three-in-one charging may cause the watch to disconnect. Use a 9V adapter to avoid this issue.

3. The maximum charging power for iPhone 12 to 15 series is 15W. Samsung phones support a maximum charging power of 10W, while some Android mobile phones support a maximum of 5W.

Specifications

Input	9V/3A, 12V/3A
Magsafe Power	15W
Earbuds Power	5W
Watch Power	2.5W
Input Interface	Type-C
Product Dimensions (Folded)	27.2×65.18×99.18mm
Product Dimensions (Extended)	65.18×99.18×103mm
Included in the Package	USB-C to USB-C Cable

Safety Precautions

1. Carefully read all instructions before using the product.
2. When using this product for the first time, perform a full charge and discharge cycle to extend its service life.
3. Ensure the device you want to charge is compatible with the power bank's specifications.
4. Keep the power bank out of reach of children, infants, and pets.
5. Avoid dropping or subjecting the power bank to impacts.
6. Do not expose the power bank to water or immerse it in water.
7. **Warning:** If the power bank comes into contact with water, do not use it.
8. Do not puncture or disassemble the power bank. Do not disassemble the product under any circumstances, as this will void the warranty.
9. Never throw the power bank into a fire, as it may cause an explosion.
10. If the power bank malfunctions or is swallowed, stop using it and contact a service center immediately.
11. Do not dispose of the power bank as household waste.
12. Avoid leaving the power bank in a car on hot days. Do not expose the battery to direct sunlight, fire, or extreme heat.
13. Do not use the power bank in environments with high temperatures or humidity.
14. Always monitor the power bank when it is charging other devices or being charged. Never leave it unattended.
15. Disconnect the charger once the battery is fully charged; do not leave it charging for an extended period.
16. Improper battery replacement may result in an explosion. Use only the same or equivalent battery type, and ensure replacement is performed by maintenance personnel, not by unqualified individuals.

- 17.** Improper battery replacement may result in an explosion. Use only the same or equivalent battery type, and ensure replacement is performed by maintenance personnel, not by unqualified individuals.
- 18.** When using a power adapter for charging, only use a branded certified adapter that complies with standard requirements.
- 19.** Do not place the equipment too close to magnetic cards (e.g., ID cards, bank cards) with magnetic stripes or chips to prevent magnetic card failure.
- 20.** Do not use a 5V adapter, as insufficient power may cause charging interruptions. Use a 9V adapter for a stable power supply.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:
powerology.me/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **powerology.me**

Instagram: **powerology_official**

Facebook: **powerology.ME**