



Powerology

50000mAh Power Bank

SKU: PPBCHA68

Table of Contents

Overview	2
Specifications	2
Charge the Power Bank	2
Charge a Phone	3
Charge Other Digital Devices	3
Safety Warnings	4
Precautions	5
Disposal	6
Warranty	7
Contact Us	7

Overview

Thank you for choosing our company's products! This device is a portable charging solution designed for digital devices such as mobile phones, tablets, e-books, and game consoles. It features high-quality lithium-ion polymer batteries and advanced charging and discharging chips, delivering a valuable and reliable user experience.


Specifications

Battery Power	50000mAh, 3.7V, 185Wh
Type-C1 Input/Output	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3A 60W Max.
Type-C2 Input	5V/3A 15W
Type-C3 Input/Output	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A 65W
USB A1 Output	5V/3A, 9V/2A, 12V/1.5A, 5V/4.5A, 4.5V/5A 22.5W
USB A2 Output	5V/2A 10W
USB A3 Output	5V/3A, 9V/2A, 12V/1.5A, 5V/4.5A, 4.5V/5A 22.5W
Product Dimensions	69×72×139mm
Weight	1070g

Charge the Power Bank

Connect one end of the charging cable to the charger and the other end to the power bank. When the indicator light flashes, it signifies that the power bank is charging. It is recommended to use a fast-charging adapter for an improved charging experience.

Note: If the power bank encounters abnormal conditions, such as overcharging or over-discharging, it will automatically activate protection mode and stop functioning. To reactivate the power bank, recharge it to restore normal operation.




Charge a Phone

1. Connect one end of the charging cable to the output port of the mobile power supply and the other end to the mobile phone that needs to be charged. The indicator light on the mobile power supply will turn on, indicating it is in the charging state.
2. If the mobile power supply encounters abnormal conditions, such as overcharging or over-discharging, it will automatically enter protection mode and stop functioning. To reactivate the mobile power supply, recharge it.

Charge Other Digital Devices

Connect one end of the charging cable to the output port of the

mobile power supply and the other end to the digital device (e.g., a tablet) that needs to be charged.



Safety Warnings

Improper use may result in battery failure, excessive heat, fire, or even an explosion. To avoid personal injury and property damage, please strictly adhere to the following guidelines when using and storing this product:

- 1.** This product is not a toy. Keep it out of reach of children and ensure they do not use or play with it to prevent accidents.
- 2.** Use a charger that complies with local safety standards to avoid electric shock or battery damage.
- 3.** Avoid pressing, hitting, dropping, or subjecting the product to strong vibrations. If any of these occur, or if liquid seeps or splashes into the product, it may cause damage.
- 4.** If the battery or circuit is damaged or short-circuited, stop using the product immediately and dispose of it properly.
- 5.** If the product becomes bulging, deformed, leaking, or shows a significant reduction in capacity, stop using it immediately and dispose of it responsibly.

- 6.** Do not place this product in pockets, airtight packages, beds, sofas, or other locations that could obstruct heat dissipation.
- 7.** Ensure the product is not covered by clothing, pillows, bedding, or other objects during use.
- 8.** It is strictly prohibited to disassemble, squeeze, puncture, or short-circuit this product. Do not throw it into water or fire (including near heat sources such as stoves or radiators) or expose it to environments exceeding 60°C (140°F).
- 9.** In hot weather, avoid placing this product in an unattended car or areas exposed to direct sunlight.
- 10.** This product contains a lithium polymer battery. Do not disassemble the product case without proper authorization to prevent potential damage to the battery or other hazards.

Precautions

- 1.** For first-time use, fully charge this product.
- 2.** When charging this product or using it to charge other devices, choose a suitable charger and data cable (it is recommended to use a high-quality charger and data cable from a reputable brand).
- 3.** While charging, ensure that someone is present and unplug the power supply if you are leaving or going out for an extended period.
- 4.** Once this product is fully charged or has fully charged other devices, disconnect the cable promptly to avoid potential damage caused by prolonged connection.
- 5.** If the battery indicator does not light up after pressing the button, the product may be in protection mode. Connect an external charger to attempt restoration.
- 6.** If the product will not be used for a long time, maintain its charge at approximately 50 % and store it in a cool, dry environment. Avoid long-term storage with a completely full or empty battery to extend

battery life.

Note: The illustrations of products, accessories, user interfaces, etc., in this manual are schematic diagrams for reference only. Due to product updates and upgrades, there may be slight differences between the actual product and the diagrams. The actual product shall prevail.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:
powerology.me/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **powerology.me**

Instagram: **[powerology_official](https://www.instagram.com/powerology_official)**

Facebook: **[powerology.ME](https://www.facebook.com/powerology.ME)**