



Powerology

Waterless Scent Diffuser

SKU: PSM006

Table of Contents

Product Overview	2
Safety Guide	2
Replacing the Nozzle	3
Features	3
Specifications	4
Using Guide	5
Light Indicator Guide	6
Using the Remote Control	8
Troubleshooting	9
Maintenance	9
App Connection	10
Disposal	12
Warranty	13
Contact Us	13

Product Overview



Safety Guide

- 1. The diffuser should always be used in an upright position. Do not tilt the diffuser, as oil may spill inside and damage the device.
- 2. Do not use the device with any other power cords. Please use the original power cord that comes with the diffuser. Ensure the power cord is positioned to prevent tripping hazards.

Replacing the Nozzle

- Unplug the diffuser and remove the fragrance oil bottle. Pull out the small tube. Using tweezers, gently pull out the black nozzle.
- 2. Replace it with a new nozzle and ensure that the nozzle is pressed very firmly into the top of the diffuser. Then, reinsert the tube into the nozzle.
- 3. It is very important that you position the tube correctly within the nozzle. Otherwise, the device will not diffuse the scent.
- 4. Within the nozzle, there is a small round tube holder where the tube needs to be firmly secured.

Tip: If you have difficulty seeing the tube holder in the nozzle, hold a flashlight into the nozzle to increase visibility.

Features



The scent diffuser utilizes the latest cold-air diffusion technology, which turns any of our hotel-inspired fragrance oils into a dry, nomist vapor. This allows the scent to linger in the air for much longer while providing superior, long-lasting coverage. It uses no water or heat, preserving the therapeutic properties of our fragrance oils without altering their smell. It features advanced atomization technology, making it residue-free and safe for pets, children, artwork, and furniture. This model comes with an easy-to-use

Specifications

Model Number	SM006
Input	DC 5V/2A
Power	10W
Charging Interface	Type-C
Noise	<30dB
Bottle Capacity	120ml

The package includes the diffuser with an empty 120mL bottle, remote control, USB cable, adapter, and user manual.

The remote control is designed for convenient adjustment of fragrance concentration levels to suit your preferences, as well as setting the desired operating duration for the device.

Please follow the instructions set out in this manual and use the device correctly.



Using Guide



Step 1: Remove the empty bottle. Twist the upper part of the diffuser counterclockwise to remove the empty bottle.



Step 2: Add the fragrance oil. Rotate the bottle counterclockwise to remove it. Fill the bottle with your favorite fragrance.



Step 3: Reinsert the bottle and upper part. Reinsert the upper part of the device. Twist clockwise to ensure a tight fit.



Step 4: Power on the diffuser. Connect the device with the USB-C cable and adapter. Use the remote to turn on the device or hold the large light indicator in the front for 2 seconds.

Please note: In the default settings, the diffuser will emit scent for 30 seconds and then pause for 60 seconds. This cycle will continue for 4 hours, after which the device will turn off automatically.

Light Indicator Guide

The light indicator on the front of the device serves as both a power button and a control for misting and timer settings once the device is turned on.


- 1. To turn the device on, press and hold the light indicator for 2 seconds.
- 2. In the default setting, the device will release scent for 30 seconds and then pause for 60 seconds. This cycle will continue for 4 hours, after which the device will turn off automatically.
- 3. To control the misting and device timer using the light indicator, follow these steps:
- 4. Misting Control: After the device is turned on, use the light indicator to adjust the misting settings.



- Press once: The diffuser emits scent for 30 seconds, then pauses for 60 seconds.
- 2. Press again: The diffuser emits scent for 30 seconds, then pauses for 120 seconds.
- 3. Press again: The diffuser emits scent for 30 seconds, then pauses for 180 seconds.

- 4. Press again: The diffuser emits scent for 30 seconds, then pauses for 240 seconds.
- 5. Press again: The diffuser emits scent for 30 seconds, then pauses for 300 seconds.
- 6. Press again: The diffuser emits scent for 30 seconds, then pauses for 360 seconds.
- 7. Timer Settings:
- 7.1 To adjust the timer setting, use the instructions below. This setting allows the device to cycle through the misting process for an extended period until the device automatically powers off.
- 7.2 Press twice for 1-hour timer: The first small LED light below the larger indicator light will power up.
- 7.3 Press twice for 2-hour timer: The first and second small LED lights below the larger indicator light will power up.
- 7.4 Press twice for 4-hour timer: The first, second, and third small LED lights below the larger indicator light will power up.
- 7.5 Press twice for 8-hour timer: The first, second, third, and fourth small LED lights below the larger indicator light will power up.
- 7.6 Press twice to cancel timer: All four small LEDs below the larger indicator light will turn off.

Remote Control



Using the Remote Control

- **ON** Press to turn on the device.
- **{OFF}** Press to turn off the device.
- {AROMA} Press the "AROMA" button while the device is on to reset the device to its factory settings.
- The settings determine the duration for which the device will emit mist before turning off. This cycle will repeat until the set time interval is completed:
- **{L1}** The diffuser will emit scent for 30 seconds, followed by a 60-second pause.
- **{L2}** The diffuser will emit scent for 30 seconds, followed by a 120-second pause.
- **{L3}** The diffuser will emit scent for 30 seconds, followed by a 180-second pause.
- **{L4}** The diffuser will emit scent for 30 seconds, followed by a 240-second pause.
- **{L5}** The diffuser will emit scent for 30 seconds, followed by a 300-second pause.
- **{L6}** The diffuser will emit scent for 30 seconds, followed by a 360-second pause.
- Timer Settings allow the diffuser to run continuously for a specified period and automatically shut off after the set time has elapsed: {1h} 1 hour, {4h} 4 hours, {8h} 8 hours

Troubleshooting

Problem	Solution
No missting	 Check the power supply. Check the "Misting hole" to ensure the device is pumping air. Ensure that the top part of the diffuser is tightly secured to the bottom by turning it clockwise. Ensure that the bottle is tightly screwed into the diffuser head.



Maintenance

The scent diffuser should be cleaned every 1 to 2 months to ensure optimal performance. To clean the inner workings of the device, please follow these steps:

- Rotate the upper part of the diffuser and fill the bottle with rubbing alcohol.
- 2. Install the upper part with the bottle back onto the diffuser.
- 3. Turn on the diffuser and run it for 15 minutes to allow the alcohol to flow through the entire device.
- 4. Remove the power cord from the diffuser and ensure the diffuser remains in an upright position.
- 5. Wipe the device with a damp cloth to remove oil stains and fingerprints. Avoid using harsh or abrasive materials to clean the device.

App Connection

Please turn on Wi-Fi and Bluetooth when the mobile phone connects to the device. Easily switch the device on/off, adjust mist settings, set timers, and schedule your device, all from your smartphone for ultimate convenience and efficiency.



Scan the QR code and download the Smart Life App.



1. Turn on the app and select the device.



2. Input the Wi-Fi password to which your phone is connected.



3. The connection was successful.



4. Enter the Home page.

App Control





Power On and Off



Misting Mode



Timer



Add Schedule

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check: powerology.me/warranty



Contact Us

If you have any questions about this Privacy Policy, please contact

us at: hey@powerology.me

Website: powerology.me

Instagram: powerology_official

Facebook: powerology.ME