



Powerology

**ULTRA MINI 20000mAh
POWER BANK**

SKU: PPBCHA79



Table of Contents

Product Overview	2
Specifications	2
Product Features	2
Safety Precautions	3
Disposal	5
Warranty	6
Contact Us	6

Product Overview

The Powerology Ultra Mini 20000mAh Power Bank is a compact and efficient portable charger offering 100W MagSafe charging. With a built-in display, it allows users to track their charging status easily. The power bank supports simultaneous charging of multiple devices and can charge laptops with its 15W output. Its lightweight design makes it ideal for on-the-go use, providing reliable power when you need it most.

Specifications

Battery Capacity	20000mAh
USB-C Input	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/2.25A, 45W Max
USB-C Output	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/5A, 100W Max
USB-A Output	5V/3A, 9V/2A, 12V/1.5A, 10V/2.25A, 22.5W Max
Wireless Output	5W, 7.5W, 10W, 15W
Product Size	25 x 80 x 90mm
Product Weight	334g ± 10
Model Number	PPBCHA79

Product Features

- 100W PD Output: Delivers fast charging for your devices.
- 20000mAh Capacity: Provides high capacity for longer-lasting power.
- Built-in Display: Shows real-time battery status for convenience.
- Simultaneous Charging: Charge multiple devices at once without interruption.

Laptop Charger: Capable of charging laptops, offering versatile usage.

MagSafe Compatibility: Ensures secure attachment for wireless charging.

Ultra Mini Design: Compact and portable, easy to carry on the go.

Safety Precautions

A. Before Using

When using this product for the first time, perform a full charge and discharge cycle to extend its service life.

Ensure the device you want to charge is compatible with the power bank's specifications.

Keep the power bank out of reach of children, infants, and pets.

Avoid dropping or subjecting the power bank to impacts.

Do not expose the power bank to water or immerse it in water.

Warning: If the power bank comes into contact with water, do not use it.

Do not puncture or disassemble the power bank. Do not disassemble the product under any circumstances. This may cause overheating, fire, or an explosion.

Never throw the power bank into a fire, as it may cause an explosion.

If the power bank malfunctions or is swallowed, stop using it and contact a service center immediately.

Do not dispose of the power bank as household waste.

Avoid leaving the power bank in a car on hot days. Do not expose the battery to direct sunlight, fire, or extreme heat.

Do not use the power bank in environments with high temperatures or humidity. Store it in a cool, dry place when not in use.

Always monitor the power bank when it is charging other devices or being charged. Never leave it unattended.

Disconnect the charger once the battery is fully charged. Do not leave it charging for an extended period.

Improper battery replacement may result in an explosion.

When using a power adapter for charging, only use a branded

certified adapter that complies with standard requirements.

B. While Using

Warning: To prevent fires, electric shocks, strangulation hazards, or injuries, please adhere to the following precautions:

Do not use, install, or store the product in the following areas:

Locations easily accessible to children, unstable surfaces, dusty or excessively damp environments, and areas exposed to direct sunlight, high temperatures, or near heat-producing objects.

Do not get the product wet or place it in any liquid or expose it to foreign objects. If any liquid or debris enters the device or wires, stop using it immediately.

Avoid subjecting the product to strong impacts or excessive force. Do not expose the device or wires to heat sources.

Do not disassemble or modify the product. If the device is damaged or deformed, cease use immediately and refrain from attempting repairs yourself.

Ensure that the ports do not come into contact with metal objects.

Regularly clean the ports and plugs with a dry cloth or swab to prevent dust buildup.

Caution: To avoid damage, malfunction, or improper operation, please ensure the following:

Do not scratch or press directly on the surface of the LCD screen.

Avoid placing the LCD screen in direct sunlight for extended periods. If using near a window, ensure the screen is not exposed to direct sunlight.

Do not apply excessive pressure to the LCD screen or its surrounding areas, as this may cause malfunction due to the screen's limited bearing capacity.

Do not connect the product to devices that are incompatible with it.

Do not use thinners, gasoline, alcohol, or other solvents to clean the product.

Avoid using or placing the device in environments where temperature fluctuations are sudden, as this could cause condensation on the display. Dispose of the product in accordance with local government guidelines when it is no longer in use.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:
powerology.me/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **powerology.me**

Instagram: **powerology_official**

Facebook: **powerology.ME**