



Powerology
Clip-On LED Light

SKU: PCMPLGHT



Table of Contents

Safety Precautions	2
Features	2
Specifications	3
Product Overview	3
Operating Modes	4
Charging	4
Maintenance	4
Environmental Protection	4
Disposal	5
Warranty	6
Contact Us	6

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Safety Precautions

1. Do not shine the light directly into your eyes, another person's eyes, or an animal's eyes.
2. Do not allow children to use the light.
3. Do not use the light if you suspect that the battery or the light casing is damaged.
4. **Warning!** To reduce the risk of burns or fire:
5. Do not attempt to open, disassemble, modify, or service the batteries.
6. Do not crush, puncture, short circuit, or dispose of batteries in fire or water.
7. Do not expose to temperatures above 60°C (140°F).

Features

1. This 150 to 200 Lumen clip light features an integrated auto-sensor and is designed for versatility.
2. The product can be attached to a supplied headband or to a cap.
3. The LED light offers directional torch functionality and a top spotlight with four settings, including a red light option.
4. The light is engineered to allow quick alternation between settings and includes a flip-up feature for swift mode changes.
5. The light is equipped with two magnets on the bottom, enabling standalone use as a work light.

Specifications

Input	5V/1A
Charging Port	Type-C
Working Time	40 Lumens, 12H and 150 to 200 Lumens, 2H
Recharge Time	1.5H
Brightness	3 Levels
Color Temperature	7000-5500K

Product Overview

- A.** Sensor Receiver Spotlight
- B.** On / Off Switch and Motion sensor switch
- C.** Charging Port: The indicator turns red/green to show charging status.
- D.** Flood Light
- E.** [On the Back] Cap Clip / Headband Clip and Magnets



Operating Modes

1. LED Floodlight Low: Press the on/off switch once to activate the low floodlight.
2. LED Floodlight High: Press a second time to activate the high floodlight.
3. LED Floodlight Red: Press a third time to activate the red light.
4. LED Spotlight: Press a fourth time to activate the spotlight.
5. Turning off: Press again to turn the light off.
6. Sensor mode: Activate the sensor by waving your hand at the sensor switch. This mode is operational in any previously selected mode. A green light will flash near the charging point to confirm sensor mode activation.

Charging

This device includes a USB Type C input and comes with a USB cable for quick and efficient charging. A red indicator strobes when the green light remains on after the device is fully charged.

Maintenance

1. Clean the torch by wiping it with a damp cloth.
2. Store the torch in a dry, childproof area.

Environmental Protection

Recycle materials that are no longer needed instead of discarding them as waste. Ensure that all tools, accessories, and packaging are sorted and taken to a recycling center where they can be processed in a manner that is environmentally friendly. Should the product become completely non-functional and require disposal,

properly drain any fluids (if applicable) into designated containers. Follow local regulations for the disposal of the product and any related substances.

Disposal

At the end of its service life, dispose of this product in accordance with the EU Directive on Waste Electrical and Electronic Equipment. If the product is no longer needed, it should be disposed of in a manner that protects the environment. For recycling information, please contact your local waste management authority.



Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:
powerology.me/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **powerology.me**

Instagram: **[powerology_official](https://www.instagram.com/powerology_official)**

Facebook: **[powerology.ME](https://www.facebook.com/powerology.ME)**