

POWER OLOGY




User Manual
WiFi Smart Outdoor Camera


PSOWCFWH

1.Product Introduction


Packing list: Smart Camera × 1, Manual × 1, USB Power Cord × 1,
Power Adapter × 1,Screw Accessories Package x 1




Smart Camera



Screw Accessories Package



USB Power Cord



Power Adapter

01

Basic Parameters

Product Model: PSOWCFWH
Pixel: 1.0Mp/2.0MP
Video Compression: H.264 High Profile
Image Enhancement: Digital Wide Dynamic 3D Noise Reduction
Local Storage: MicroTF card
Wireless Encryption: WEP/WPA/WPA2 Encryption
Power Input: 5V 1A(Min)
Total Power Consumption: 5W (Max)
WirelessStandard: 2.4G 802.11 b/g/n
Support Platform: Android/iOS

Component Description:


Reset Button: Long press "reset" hole 5sec, reset success.

It is recommended to insert 8-128GB high-speed Micro TF card, otherwise it will not be able to store, view historical video and support Important functions such as firmware upgrading.

02

2.Install APP


Download APP: scan the QR code below to download and install.
Register and login: open the" APP" to register and login according to the prompts.



03


3.1 Add The Device-Scan QR code mode

· Make sure Wi-Fi is available and connected to the Internet.
· Connect the camera to the power, then system startup completed.
· Open "APP" press the '+' in the upper right corner of the main screen (Figure 01); choose "Security & Sensor" click "Smart Camera" (Figure 02) to add camera; and then click "Next step" (Figure 03);




04

·If the mobile phone is not connected to wi-fi, please click "Connect to Wi-fi" (Figure 04);
·It will jump to the WLAN interface and connects Wi-Fi (Figure 05).Please note that only 2.4 GH Wi-Fi network is supported;
·If the phone is connected to Wi-Fi (Figure 06) ;




05

·A QR code will prompt on your screen and you need to scan it with the Smart Camera. (the camera is about 20-30 cm away from the mobile phone lens). Then click "hear the prompt sound" (Figure. 07). "connecting" (Figure. 08);




06

·Connection completed (Figure 09), and click "Finish";
·Then jump to preview interface (Figure 10)
·After closing the device preview interface, the interface returns to the APP home page. At this time, the connected device will appear on the APP home page (Figure 11). Then you can click directly to the device interface to see the monitoring situation without re-adding afterwards.



07

4.APP Video Browsing Details



①Preview mode ②Monitor Switch ③About device
④Signal Value ⑤Full screen

08

5.Matters Need Attention

Try to keep away from the metal space;
Avoid the furniture , microwave oven blocked;
Avoid the space where the audio, video and data lines are wound, and keep the space away from them as large as possible;
Ensure that as close as possible to the coverage of wireless Wi-Fi signals. Switching network environment;
In the new network environment, please press the reset hole about 5 seconds, then connect to the network.

09

The name and content of the harmful substances in the product

Part Name	Harmful Substance					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
shell	○	○	○	○	○	○
Board	X	○	○	○	○	○
charger	○	○	○	○	○	○
annex	○	○	○	○	○	○

This form is based on the provisions of SJ/T 11364.
This product conforms to RoHS environmental protection requirements. At present, there is no mature technology in the world to replace or reduce the lead content in the electronic ceramics. porcelain, optical glass, steel and copper alloy.

10

Maintenance records: _____

Maintenance time: _____

Fault conditions: _____

Fault cause: _____

Troubleshooting: _____

Return and exchange proof: _____

Date of validity: _____

Original device ID: _____

New device ID: _____

maintenance personnel signature: _____

Maintenance Department seal: _____

Maintenance voucher of intelligent

Customer: _____ Mobile: _____

Address: _____

Model: _____ Camera ID: _____

Device store: _____ Date of purchase: _____

Store address: _____

Store contact number: _____

Maintenance voucher of intelligent

Customer: _____ Mobile: _____

Address: _____

Model: _____ Camera ID: _____

Device store: _____ Date of purchase: _____

Store address: _____

Store contact number: _____

Maintenance voucher of intelligent

Customer: _____ Mobile: _____

Address: _____

Model: _____ Camera ID: _____

Device store: _____ Date of purchase: _____

Store address: _____

Store contact number: _____

Maintenance voucher of intelligent

Customer: _____ Mobile: _____

Address: _____

Model: _____ Camera ID: _____

Device store: _____ Date of purchase: _____

Store address: _____

Store contact number: _____