



# **Powerology**

### **LOVANNI AI Smart Glasses**

SKU: PWAICMBK

# Table of Contents

Product Overview	2
Specifications	2
Schematic View	3
Button Functions	3
Connection Guide	4
Important Notes	5
Safety Precautions	5
Disposal	5
Warranty	6
Contact Us	6

# Product Overview

The Powerology Lovanni AI Smart Glasses combine cutting-edge technology with stylish design, offering an immersive and interactive experience. Powered by AI, these smart glasses feature a high-resolution 32MP camera capable of capturing stunning photos and recording 30fps video with software anti-shake. The built-in AI voice assistant allows for hands-free control and real-time object recognition, making daily tasks easier. Additionally, the glasses provide immersive stereo audio with dual 3W stereo speakers and ENC technology, ensuring clear sound for music, calls, and notifications. With wireless connectivity, the glasses effortlessly connect to devices, enabling file transfer and seamless media sharing. Ideal for those looking to merge fashion with advanced technology, the Lovanni AI Smart Glasses offer a truly innovative and practical wearable experience.

### **Specifications**


Model Number	PWAICM
Battery Capacity	290mAh
Battery Life	10 Hours
Standby Time	15 Days
Recharge Time	90 Minutes
Charging Method	Magnetic Charging
Camera	Sony IMX219 32MP
Image Resolution	4920 × 6560
Video Resolution	1200 × 1600
Speaker Size	13mm
Bluetooth Version	5.3
ROM	2GB

2

Wi-Fi Frequency	Wi-Fi 2.4 ,4.0GHz
Shell Material	PC + ABS and TR90
Product Size	49 × 153.5 × 176mm
Product Weight	55.3g

### **Schematic View**

- 1. Charging contact point
- 2. Touch control area
- Lower button
- 4. Upper button
- 5. Camera
- 6. Indicator Light



Note: Only the right handle has a touch area and buttons.



#### **Button Functions**

#### **Upper Button**

- a. Power On/Off: Press and hold for 2 seconds to turn on; press and hold for 5 seconds to turn off.
- b. Reset to Factory Settings: Press and hold for 10 seconds.
- c. Take a Photo: Single click.
- d. Record Video: Double-click to start; during recording, single-click to s top.
- e. Answer a Call: During an incoming call, single-click to answer, press and hold for 2 seconds to reject; during a call, single-click to end the call.

#### **Lower Button**

- a. Activate Al Voice Assistant:
  Single-click to activate/exit.
- b. Al Quick Image Recognition:Double-click.
- c. Recording:

  Long-press to start recording;

  click to stop.

#### **Touch Area**

 $\bigcirc$ 

a. Play/Pause Music:

Double-click the touch area.

(1)

b. Adjust Volume: Swipe forward

to increase volume, swipe backward

to decrease volume.

(k)

c. Skip to Next Track: Triple-click

the touch area.

(**Q**)

d. Activate Phone Voice Assistant:

Long-press to activate/exit.



#### **Connection Guides**

These smart glasses are independent devices, but many of their functions require a connection to a phone for full use. To get started, simply scan the provided QR code, select the appropriate system version, and download the app "HeyCyan" directly to your phone



Hey Cyan
use QR code from
the package

To connect via Bluetooth, open the installed app and follow the prompts to complete registration. Then, select "Home" and click "Connect Device". Choose the detected device name (Q8), and once you hear a ding sound, the connection will be successful.

## Important Notes

This product supports photography and video recording, but these functions consume relatively high power. When the battery level drops below 15%, the device will disable photography and video recording functions. When the battery level drops below 20%, the device will pause data transmission to the phone. After charging, these functions can be restored.

This product supports Wi-Fi data transmission to the phone and storage. This feature requires the phone to grant the app the necessary permissions. (Please make sure to turn on your phone's Wi-Fi before transferring files.)

### Safety Precautions

- 1. Do not charge the device in environments with water stains or humidity.
- 2. Use the charging cable provided with this product for charging. This product is made of soft materials. Handle with care and avoid dropping or impacting it. If any damage is detected, handle with caution to avoid injury.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.





Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **https://www.powerology.me/warranty** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:

https://www.powerology.me/warranty



If you have any questions about this Privacy Policy, please contact

us at: hey@powerology.me

Website: https://www.powerology.me/

Instagram: powerology\_official

Facebook: powerology.ME