



Powerology

MAGNOVA 25W
MagSafe Charging Pad

SKU : PWTKWC068SL



Table of Contents

Product Overview	2
Specifications	2
Instructions for Use	2
Safety Precautions	3
Maintenance and Care	4
Disposal	5
Warranty	5
Contact Us	5

Product Overview

The Powerology Magnova 25W MagSafe Charging Pad is a reliable and efficient wireless charging solution designed to provide fast and secure charging for compatible devices. With a sleek, ultra-thin design and a 1.2-meter cable length, this charging pad offers ease of use and convenience. The device features a tangle-free cable, universal compatibility with various devices, and built-in safeguards to ensure safe operation. Its MagSafe compatibility ensures a secure and stable connection, while the aluminum alloy housing adds durability and a premium finish. This charging pad is the ideal choice for quick, hassle-free charging, providing an effortless solution for your power needs.

Specifications

Model Number	PWTKWC068
Material	PC + Aluminum Alloy
Braiding Material	Fabric
Input	5V/3A, 9V/3A, 15V/2A
Wireless Output	25W Max
Cable Length	1.2m
Input Connector	USB-C
Product Size	6.9 x 56.2 x 56.2mm

Instructions for Use

1. Setting Up:
Place the charging pad on a flat, stable surface.

2. Connect the USB Cable:

Connect the USB cable to the PD (Power Delivery) power adapter.

3. Place Your Device for Charging:

Position your wireless charging device in the designated charging area. The charging icon will appear at the top of your device's screen to indicate that it is charging.

4. Powering Off:

The charging pad does not require turning off manually. Disconnect the USB-C cable when the charging session is complete.

Safety Precautions

1. Do Not Overheat:

Ensure the charging pad is placed in a well-ventilated area to avoid overheating. Avoid covering the charging pad while it is in use, as this could block airflow and lead to overheating, potentially affecting charging performance or damaging the device.

2. Device Compatibility:

This charging pad is optimized for MagSafe-compatible devices. Always ensure that your device supports wireless charging before use. For optimal performance, use a MagSafe-compatible device or a device that supports Qi wireless charging.

3. Avoid Water Exposure:

Keep the charging pad away from water, moisture, or any liquids to prevent potential damage to the device and avoid electrical hazards. Do not expose the charging pad to rain or any wet conditions.

4. Proper Handling:

Handle the charging pad with care. Avoid dropping or subjecting it to heavy impacts, as this may damage internal components or compromise the charging functionality.

5. Avoid Extreme Temperatures:

Do not use the charging pad in extremely hot or cold environments. Excessive temperatures may reduce charging efficiency or damage the device over time. For best performance, use it in a temperature range of 10°C to 40°C (50°F to 104°F).

6. Check for Obstructions:

Before placing your device on the charging pad, ensure there are no obstructions between the charging pad and the device. Metal objects or other non-compatible devices placed on the charging pad can interfere with charging and may cause damage.

7. Use Certified Cables:

Always use the provided USB-C cable or a certified, high-quality cable for charging. Using non-certified cables may result in slower charging speeds or potential hazards.

Maintenance and Care

1. Regular Cleaning:

Keep the charging pad clean and free from dust, dirt, or debris. Wipe it down regularly with a soft, dry cloth to maintain the performance and aesthetic appearance. For stubborn stains, use a slightly damp cloth (avoid soaking) and gently wipe the surface.

2. Cable Care:

Avoid twisting, pulling, or knotting the charging cable. Store the cable in a neat, coil-like fashion when not in use to prevent wear and tear on the cable and connectors.

3. Store Properly:

When not in use, store the charging pad in a safe, dry location away from extreme temperatures and humidity. Avoid exposing the charging pad to direct sunlight for prolonged periods.

4. Inspect Before Use:

Before each use, visually inspect the charging pad, cable, and power adapter for any signs of damage or wear. If you find any damaged components, discontinue use immediately and replace the affected parts.

5. Avoid Using While Wet:

Never use the charging pad if it is wet or exposed to water. Ensure that both the charging pad and the device are dry before connecting them.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

Warranty

Products that you buy directly from our **Powerology** website or shop come with a 24-month warranty.

The 24-month warranty applies to products purchased directly from our **Powerology** website or store. If **Powerology** products are bought from any of our verified retailers, then the product is eligible for only a 12-month warranty. To extend your product's warranty, visit our website **<https://www.powerology.me/warranty>** and fill in your details in the provided form along with an uploaded picture of the product to process your request. Once approved, you will receive a confirmation email of the extended product warranty. Upload the required information within 48 hours of purchase to be eligible for a 24-month warranty period.

For more info, please check:

<https://www.powerology.me/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at: **hey@powerology.me**

Website: **<https://www.powerology.me/>**

Instagram: **[powerology_official](#)**

Facebook: **[powerology.ME](#)**